




DATA TRANSLATION

UM-25242-A

***QuickDAQ 2013
User's Manual***



**First Edition
January, 2013**

Copyright © 2013 by Data Translation, Inc.
All rights reserved.

Information furnished by Data Translation, Inc. is believed to be accurate and reliable; however, no responsibility is assumed by Data Translation, Inc. for its use; nor for any infringements of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent rights of Data Translation, Inc.

Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer software clause at 48 C.F.R. 252.227-7013, or in subparagraph (c)(2) of the Commercial Computer Software - Registered Rights clause at 48 C.F.R., 52-227-19 as applicable. Data Translation, Inc., 100 Locke Drive, Marlboro, MA 01752.

Data Translation, Inc.
100 Locke Drive
Marlboro, MA 01752-1192
(508) 481-3700
www.datatranslation.com
Fax: (508) 481-8620
E-mail: info@datx.com

Data Translation® is a registered trademark of Data Translation, Inc. QuickDAQ™, MEASURpoint™, TEMPpoint™, and VOLTpoint™ are trademarks of Data Translation, Inc.

All other brand and product names are trademarks or registered trademarks of their respective companies.

Table of Contents

About this Manual	9
Intended Audience.....	9
Organization of this Manual.....	9
Conventions Used in this Manual	10
Related Information.....	10
Where to Get Help	10
Chapter 1: Introduction to QuickDAQ	11
Features	12
Supported Devices	12
Supported Functions.....	12
Modes of Operation.....	13
Resolution Requirements	14
Chapter 2: Quick Start.	15
Installing the Software.....	16
Getting Started	17
Chapter 3: Understanding the Interface	23
Overview of the Interface	24
Menus.....	25
File Menu	25
New Hpf Data File	25
Open Hpf Data File	25
Close Hpf Data File	26
Export Data	26
Save Current Plot Image	27
Open Current Data in Excel	28
Load Configuration	28
Save Configuration	28
Page Setup	28
Print Preview	28
Print	28
Exit	29
Exit without saving current configuration	29
Edit Menu.....	29
Record Menu	29
Plot Menu.....	30
Configuration Menu.....	31

Windows Menu	31
Help Menu	32
Toolbar Buttons	33
Window Positioning	35
Hiding a Window	36
Resetting the Window Layout	37
Acquisition Config Window	38
Plot and Data Config Window	40
Channel Plot Window	41
Setting Up the Y-Axis	42
Y Axis Setup	42
Zoom to Fit in View	43
Zoom to Fit All	43
Setting Up the X-Axis	43
X Axis Setup	44
Zoom to Fit All	44
Edit Label	44
Pause Tracking	44
Resume Tracking	45
Scrolling Options	45
Using the Channel Plot Window Controls	46
Tracking Resume	46
Tracking Pause	46
Axes Scroll	46
Axes Zoom	46
Zoom-Out All	47
Zoom-In All	47
Zoom All to Fit in View Y	47
Link X Axes to Selected	47
Link Y Axes to Selected	47
Link Cursors to Selected	47
Select	47
Zoom Box	47
Data-Cursor	48
Copy to Clipboard	49
Save Plot Image	49
Print	49
Preview	49
Page Setup	49
Show Legend	50
Show Data Point Markers	50

Channel Display Window	52
Statistics Window	53
Acquisition Status Window	54
Chapter 4: Configuring Channels and the Acquisition Settings.....	55
Configuring Channels of a Device.....	56
Enabling Channels	58
Channel Name.....	58
Analog Input Channel Settings for Devices that Support Temperature and/or Multi-Range Voltage Inputs.....	58
Sensor Type	58
Range	60
Engineering Unit (EU)	60
mV/EU	60
EU Offset	60
Point #	61
Analog Input Channel Settings that Support IEPE Inputs	61
Range	61
Coupling Type	61
Current Source	61
Engineering Unit (EU)	61
mV/EU	62
EU Offset	62
Point #	62
Dir	62
Analog Input Channel Settings for Devices that Support Voltage	62
Engineering Unit (EU)	63
mV/EU	63
EU Offset	63
Point #	63
Analog Input Channel Settings for Devices that Support Strain.....	63
Enable Shunt Resistor	64
Configuration and Calibration Wizard	64
Parameters for Full Bridge Based Sensors	65
Parameters for Strain Gage Sensors.....	69
Parameters for Voltage Based Sensors.....	75
Point #	76
Tachometer Settings	76
Engineering Unit (EU)	76
Ticks/Rev	76
Max RPM	76
RPM Multiplier	76

Max mSec/Hz	77
Tach Edge	77
Counter Settings	77
Engineering Unit (EU)	78
Max mSec/Hz	78
Start Edge	78
Stop Edge	78
Quadrature Decoder Channel Settings	79
Engineering Unit (EU)	79
Pulses/Rev	79
Clock Prescale	79
X4 Scaling	79
Index Mode	79
Applying and Saving Changes	80
Configuring the Settings of the Recording Tab	81
Configuring the Settings of the Acquisition Tab	84
Sampling Frequency	84
Trigger Source	85
Filter Type	85
Temperature Units	86
Single-Ended or Differential Channel Configuration	86
Input Voltage Range	86
Chapter 5: Configuring the Display	87
Configuring the Appearance of the Channel Display Window	88
Displaying Channels in the Channel Display Window	88
Making All Selected Channels Visible or Hidden in the Channel Display Window at Once	89
Showing or Hiding the Visible Display Column	89
Moving the Visible Display Column	89
Controlling How Data is Displayed in the Channel Display Window	90
Specifying the Style of the Channel Display Window	92
Configuring the Appearance of the Channel Plot Window	94
Displaying Channels in the Channel Plot Window	94
Making All Selected Channels Visible or Hidden in the Channel Plot Window at Once	95
Showing or Hiding the Visible Plot Column	95
Moving the Visible Plot Column	95
Displaying Data Cursors in the Channel Plot Window	96
Making All Selected Data Cursors Visible or Hidden at Once	96
Showing or Hiding the Show Cursor Column	97
Moving the Show Cursor Column	97

Specifying the Columns of the Channel Plot Window	97
Changing the Plot Column for All Selected Channels at Once	98
Showing or Hiding the Plot Column	99
Moving the Plot Column	99
Grouping Signals in Bands on the Channel Plot Window	99
Changing the Signal Group for All Selected Channels at Once	100
Showing or Hiding the Signal Group Column	100
Moving the Signal Group Column	100
Specifying the Trace Color on the Channel Plot Window	101
Showing or Hiding the Color Column	101
Moving the Color Column	101
Controlling How Data is Plotted in the Channel Plot Window	102
Specifying the Style of the Plots in the Channel Plot Window	104
Configuring the Appearance of the Statistics Window	105
Making Statistics for All Selected Channels Visible or Hidden in the Statistics Window at Once	105
Showing or Hiding the Visible Statistics Column	106
Moving the Visible Statistics Column	106
Chapter 6: Example Using QuickDAQ	107
Overview	108
Configure the Channels	109
Configure the Parameters of the Acquisition Config Window	111
Configure the Appearance of the Channel Display Window	113
Configure the Appearance of the Channel Plot Window	114
Configure the Appearance of the Statistics Window	117
Position the Windows	118
Start the Measurement	120
Chapter 7: Support	121
Troubleshooting	122
Technical Support	123
Index	125

About this Manual

The manual describes the features of QuickDAQ 2103, how to get started using QuickDAQ 2013, and how to create a typical application to acquire and analyze data from a data acquisition device.

Note that QuickDAQ 2013 is referred to as QuickDAQ throughout this manual.

Intended Audience

This document is intended for engineers, scientists, technicians, or others responsible for acquiring and analyzing measurement data. It is assumed that you are familiar with the Windows operating environment, that you are familiar with measurement principles.

Organization of this Manual

This manual is organized as follows:

- [Chapter 1, "Introduction to QuickDAQ,"](#) provides an overview of the features of QuickDAQ.
- [Chapter 2, "Quick Start,"](#) describes how to install and start QuickDAQ.
- [Chapter 3, "Understanding the Interface,"](#) describes the basic elements of the user interface.
- [Chapter 4, "Configuring Channels and the Acquisition Settings,"](#) describes how to configure the channels and acquisition settings of a supported device using QuickDAQ.
- [Chapter 5, "Configuring the Display,"](#) describes how to configure the settings of the Channel Plot and Channel Display windows.
- [Chapter 6, "Example Using QuickDAQ,"](#) provides step-by-step instructions that you can follow to create a measurement application.
- [Chapter 7, "Support,"](#) provides technical support information.

An index completes this manual.

Conventions Used in this Manual

The following conventions are used in this manual:

- Notes provide useful information that requires special emphasis, cautions provide information to help you avoid losing data or damaging your equipment, and warnings provide information to help you avoid catastrophic damage to yourself or your equipment.
- Items that you select or type are shown in **bold**.

Related Information

This manual is intended to be used with the documentation for your data acquisition device.

Where to Get Help

Should you encounter problems installing or using QuickDAQ, the Data Translation Technical Support Department is available to provide technical assistance. Refer to [Chapter 7](#) starting on [page 121](#) for information on how to contact the Technical Support Department.



Introduction to QuickDAQ

Features	12
Modes of Operation	13
Resolution Requirements	14

Features

QuickDAQ allows you to acquire data, record data to disk, display the results in both a plot and a digital display, and read a recorded data file.

Supported Devices

You can acquire and analyze data from a number of devices using QuickDAQ, including the following:

- All DT-Open Layers devices that support A/D streaming
- MEASURpoint instruments
- TEMPpoint instruments
- VOLTpoint instruments
- DT8824 and DT8824-HV instrument modules
- DT8837 instrument modules

Supported Functions

Using QuickDAQ, you can perform the following functions:

- Discover and select your devices.
- Configure all input channel settings for the attached sensors.
- Load/save multiple hardware configurations.
- On each device, acquire data from all channels supported in the input channel list.
- Log acquired data to disk.
- Display acquired data during acquisition in either a digital display using the Channel Display window or as a waveform in the Channel Plot window.
- View statistics about the acquired data, including the minimum, maximum, and mean values and the standard deviation in the Statistics window.
- Open recorded data in Microsoft Excel® for further analysis.
- You can customize many aspects of the acquisition, display, and recording functions to suit your needs, including the acquisition duration, sampling frequency, trigger settings, filter type, and temperature units to use.

Modes of Operation

You can use QuickDAQ in one of two modes:

- **Acquisition mode** – Use this mode if you want to acquire analog input and/or digital input data. This mode requires use of at least one of the supported Data Translation devices; refer to [page 12](#) for a list of supported devices.

You can either monitor acquired data without logging it to disk, or record the acquired data to disk.

- **File reader mode** – Use this mode if you want to view a previously recorded data file. Note that you cannot acquire new data using the File reader mode.

Resolution Requirements

A minimum vertical screen resolution of 768 is required for proper operation of QuickDAQ.

In addition, it is recommended that you set the default font size to 100%. To do this, select **Control Panel, Display**, and then choose **Smaller (100%)**.



Quick Start

Installing the Software	16
Getting Started	17

Installing the Software


A link to the QuickDAQ application is provided on the CD for your device.

You can also download the latest version of QuickDAQ by going to the Data Translation web site.

Getting Started

To get started with QuickDAQ, follow these steps:

1. Connect a supported device to the network (Ethernet/LXI devices) or to the USB port of your computer (for USB devices), and connect your sensors to the device.
2. Start QuickDAQ.
The Device Selection window appears.



Note: If you ran QuickDAQ before and the devices that were used are still present and are not acquiring data, the Device Selection window is bypassed. If the devices support password protection, you must supply the correct password before the application launches. Refer to the user's manual for your device to determine the default password.

For devices that do not support password protection and that are currently acquiring data, a warning dialog box appears notifying you that another application is using the device. You cannot continue with QuickDAQ until the device is not acquiring data.

For devices that support password protection and that are currently acquiring data, the software alerts you that the device is acquiring data and gives you the option to abort acquisition and continue, or to cancel.

3. By default, the application "discovers" all devices that are available for the specified device family and displays their IP address (for Ethernet devices) or module name (for USB devices) in the drop-down list. If you want to refresh this list to determine if other devices are available, click **Refresh**.

Notes: OpenLayersDevices is the Device Family name for all Open Layers modules.

MEASURpoint-USB is the Device Family name for the USB versions of MEASURpoint, TEMPpoint, and VOLTpoint instruments.

MEASURpoint-ENET is the Device Family name for all Ethernet versions of MEASURpoint, TEMPpoint, and VOLTpoint instruments.

DT8824 is the Device Family name for all DT8824 Series instrument modules.

DT8837 is the Device Family name for the DT8837 instrument module.


4. Select the IP address (for Ethernet devices) or module name (for USB devices) for the device that you want to use from the list of Available Devices, and click **Add**.
Information about the device, including the model number, serial number, firmware version, driver version, and scanning status is displayed.
5. For Ethernet devices, if your supported device is not included in the list of available devices, but you want to manually connect to it, do the following:
 - a. Click **Advanced**.



- b. Enter the IP address of the device that you want to connect to, and click **OK**.
Information about the device, including the model number, serial number, firmware version, driver version, and scanning status is displayed.
 - c. From the Device Selection window, click **Add**.
 - d. If the device supports password protection, the Password Required dialog box appears:




- e. If prompted, enter the password for the device. Refer to the user's manual for your device to determine the default password. If desired, check the **Mask password text** checkbox so that you cannot read the password as it is being typed, and then click **OK** to continue. (Note that the software does not allow you to continue if you do not enter the appropriate password for the device.)




Note: If the device that you want to add does not support password protection and the device is currently acquiring data, a warning dialog box appears notifying you that another application is using the device. You cannot continue with QuickDAQ until the device is not acquiring data.


If the device that you want to add supports password protection and the device is currently acquiring data, the software alerts you that the device is acquiring data and gives you the option to abort acquisition and continue, or to cancel.

6. (Recommended) If you want to rename your device, do the following:
 - a. Click the Row Selector button for the device.
 - b. Click the IP address or module name in the **Name** column to highlight it and enter a meaningful name to represent each available device.



7. (Optional) If you want to remove a device from list of selected devices, click the Row Selector button for the device, and then click **Remove**.
8. Once you have added all the devices that you want to use with the application, click **OK**. *The latest state is saved and used when the application is next run, and QuickDAQ interface is displayed.*



9. Configure the input channels of the device. (See [page 56](#).)
10. Set up the parameters of the Recording tab in the Acquisition Config window. (See [page 81](#).)
11. Set up the parameters of the Acquisition tab in the Acquisition Config window. (See [page 84](#).)
12. Configure the display. (See [Chapter 5](#) starting on [page 87](#).)
13. To start acquisition, click the **Record** menu and then click **Start**, click the **Record** toolbar button (), or press the **F5** key.
The results are displayed in the Channel Plot, Channel Display, and Statistics windows.



Understanding the Interface

Overview of the Interface	24
Menus	25
Toolbar Buttons	33
Window Positioning	35
Acquisition Config Window	41
Plot and Data Config Window	40
Channel Plot Window	41
Channel Display Window	52
Statistics Window	53
Acquisition Status Window	54

Overview of the Interface

Figure 1 shows the QuickDAQ interface. The interface includes menus, toolbar buttons, the configuration area, which includes the Acquisition Config window and the Plot and Data Config window, the display area, which includes the Channel Display window, Channel Plot window, and Statistics window, and the Acquisition Status window.

Note: You can customize the look of the interface, as desired. However, if you want to revert to the default layout, select **Windows** from the list of menus and select **Reset Window Layout to Default Layout**.




Figure 1: QuickDAQ Interface

This chapter describes the major features of the interface.

Menus

QuickDAQ provides the following menus at the top of the interface: **File**, **Edit**, **Record**, **Plot**, **Configuration**, **Windows**, and **Help**.

File Menu

This section describes the options provided in the File menu.

New Hpf Data File

When you click the **New Hpf Data File** option of the File menu or click the **New HPF Data File** toolbar button , you can create a new (empty) data file for use with QuickDAQ. You can name and save the data file, as desired. The format of this file is High Performance binary (.hpf).

By default, the data file is stored in the following location:

For Windows Vista, Windows 7, or Windows 8:

C:\Users\\AppData\Local\Data Translation\QuickDAQ\Data

For Windows XP:

C:\Documents and Settings\\Local Settings\Application Data\
Data Translation\QuickDAQ\Data

Note: To see the AppData folder, ensure that you set your view options to show hidden files. For example, in Windows 7, select **Control Panel** -> **Appearance and Personalization** -> **Folder Options**, select the **View** tab, and then select the **Show hidden files, folders, and drives** checkbox. Consult the documentation for your operating system for more information.

Open Hpf Data File

When you click the **Open Hpf Data File** option of the File menu or click the **Open HPF Data File** toolbar button , you can open an .hpf data file that was created using QuickDAQ.

A sample data file, called QuickDAQ Data.hpf, is provided, by default, in the following location:

For Windows Vista, Windows 7, or Windows 8:

C:\Users\\AppData\Local\Data Translation\QuickDAQ\Data

For Windows XP:


C:\Documents and Settings\\Local Settings\Application Data\
Data Translation\QuickDAQ\Data

Close Hpf Data File

The **Close Hpf Data File** option closes an opened data file (.hpf), restoring the previous state of QuickDAQ.

Export Data

When you click the **Export Data** menu option from the File menu, or click the **Export Data** toolbar button , the following dialog box appears:



Configure this dialog as follows:

1. Under the **Channels to Save** area of the dialog, you can select whether to save the data from all channels or only those that are visible in the Channel Plot window or Channel Display window.

To save data from all channels, select **All channels**.

To save data from only the visible channels, select **Visible channels only**.

2. Under the **Data Options** area of the dialog, select which data to save.

You can save all scans by selecting **Save all data**, or save a subset of scans by selecting **Save range of scans** and entering the first scan and the last scan to save.

3. Under the **Output File Format** area of the dialog, select the file format to use when exporting the data:
 - **Tab Delimited Text (.txt)** – This file format is used by a number of applications, including Microsoft Excel.
 - **Comma Delimited Text (.csv)** – This file format is used by a number of applications, including Microsoft Excel.
4. If you wish, you can export information about the device and channels that correspond to the saved data, by selecting the **Include device and channel info** checkbox.
5. In the **Output File Name** text box, enter or browse to the name of the file that will contain the exported data.
The path showing where the file is located is shown.

If you want to append a number to this file name and increment the number automatically each time you export data, select the **Auto-increment file name postfix #** checkbox.

The default location for saving the data files is as follows:

For Windows Vista, Windows 7, or Windows 8:
 C:\Users\\AppData\Local\Data Translation\QuickDAQ\Data

For Windows XP:
 C:\Documents and Settings\\Local Settings\Application Data\Data Translation\QuickDAQ\Data
6. Click the **Export** button to export the data to the file you specified.
7. Once the file is created, you can open the file in Microsoft Excel by clicking the **Open in Excel** button.
8. When you are finished exporting the data, close this dialog box by clicking the **Done** button.

Save Current Plot Image

The **Save Current Plot Image** option saves the current plot image from the Channel Plot window to a file.

To save the image to a file, specify the name of the file and choose one of the extensions to save the file as a graphic.

The default location for saving the current plot image files is as follows:

For Windows Vista, Windows 7, or Windows 8:

C:\Users\\AppData\Local\Data Translation\QuickDAQ\Data

For Windows XP:

C:\Documents and Settings\\Local Settings\Application Data\Data Translation\QuickDAQ\Data

Open Current Data in Excel

If you choose the **Open Current Data in Excel** menu option from the File menu or click the **Open Current Data in Excel** toolbar button , the application opens a tab-separated (.tmp.tvs) file in Microsoft Excel that contains all the time domain data for the visible channels in the Channel Plot window.

You can then perform further analysis of your data using Excel or other utilities.

Note: Before using this option, ensure that Microsoft Excel is installed on your computer. In addition, you must stop acquisition before trying to use this option, or the application cannot open the file.

Load Configuration

The **Load Configuration** option opens an .XML file of stored configuration settings.

Save Configuration

The **Save Configuration** option saves the current application configuration to a user-specified filename with the .XML extension.

The default location for saving the configuration file is as follows:

For Windows Vista, Windows 7, or Windows 8:

C:\Users\\AppData\Local\Data Translation\QuickDAQ\Config.

For Windows XP:

C:\Documents and Settings\\Local Settings\Application Data\
Data Translation\QuickDAQ\Config

Page Setup

The **Page Setup** option allows you to configure the page before you print it. Options are available for configuring the size, orientation, and margins of the page.

Print Preview

The **Print Preview** option allows you to preview the image from the Channel Plot window before you print it.

Print

The **Print** option prints the picture from the Channel Plot window to a printer.

Exit

The **Exit** option closes QuickDAQ, and saves the current device configuration in the QuickDAQConfiguration.xml file in the default configuration folder. You can also close the application by clicking the  button in the top, right-hand side of the application.

Notes: A backup configuration file (QuickDAQConfiguration.xml.bak) is saved in the default configuration folder when QuickDAQ is exited. If, when starting QuickDAQ, an error occurs and the configuration file cannot be restored, the backup file is used to restore the configuration.

If the device is acquiring data through another application, a warning dialog box appears notifying you that you cannot save the current configuration if you close the application.

Exit without saving current configuration

The **Exit without saving current configuration** option closes QuickDAQ, but does not save the current device configuration.

Edit Menu

The Edit menu has the following menu options:

- **Copy plot data to clipboard** – Copies the data from the Channel Plot window to the Windows clipboard.
- **Copy plot image to clipboard** – Copies the image from the Channel Plot window to the Windows clipboard.


Record Menu

The Record menu has the following menu options:

- **Start** – Starts data acquisition on the device and logs the data to a High Performance binary file (.hpf). This is equivalent to clicking the **Record** button ( Record) on the toolbar or pressing the **F5** key. You can specify the name of the data file by opening a new Hpf file, described on [page 25](#), or by using the **Recording** tab, described on [page 81](#).

Note: You can use the scrollbar on the x-axis to pause tracking and scroll back through the data to the beginning of acquisition. Refer to [page 44](#) and [page 46](#) for more information on pausing and resuming tracking.

For long duration acquisitions, ensure that your computer's power options are set to never hibernate; refer to [page 122](#) for more information.

- **Pause** – Pauses recording. This is equivalent to clicking the **Pause** button () on the toolbar or pressing the spacebar. To resume recording, click the **Pause** menu option, click the **Pause** button, or press the spacebar again.
- **Stop** – Stops the application from receiving data from the device. This is equivalent to clicking the **Stop** button () on the main menu or holding down the **Shift** key and pressing the **F5** key. You must stop acquisition to make configuration changes.

Plot Menu

The Plot menu has the following menu options:

- **Plot Area Mouse Mode** – You can select one of the following controls for the Channel Plot window:

- **Select** – Allows you to select items in the view area to zoom or to scroll. This is equivalent to using the **Select** control () of the Channel Plot window, or holding down the **Ctrl** and **Alt** keys while pressing the **V** key.
- **Zoom** – Allows you to select a region in the view to magnify (zoom). This is equivalent to using the **Zoom Box** () control of the Channel Plot window, or holding down the **Ctrl** and **Alt** keys while pressing the **Z** key.

Once in zoom mode, you can hold down the left mouse button, dragging the mouse to select the region that you want to magnify, and release the mouse button to magnify the area. The zoom action affects both axes.

- **Cursor** – Allows you to move the position of a data-cursor on the curve. This is equivalent to using the **Data-Cursor** () control of the Channel Plot window, or holding down the **Ctrl** and **Alt** keys while pressing the **C** key.

Once in Data-Cursor mode, hold down the left mouse button and drag the mouse to move the data cursor. When the **Data-Cursor** is active, right-click the mouse to change the cursor style, line style, and/or color of the cursor; refer to [page 48](#) for more information.

- **Axis Mouse Mode** – You can select one of the following controls for the axis:

- **Scroll** – Allows you to scroll through the axes. This is equivalent to using the **Axes Scroll** () control of the Channel Plot window.

Once in this mode, hold down the left mouse button and drag the mouse over the axis (up and down for the y-axis, or right and left for the x-axis) to scroll through the axes.

- If you want to change the magnification (zoom) of the axes while this mode is selected, hold down the **Ctrl** button while holding down the left mouse button, and drag the mouse over the axis (up and down for the y-axis, or right and left for the x-axis).

- **Zoom** – Allows you to change the magnification (the zoom) of the axes. This is equivalent to using the **Axes Zoom** () control of the Channel Plot window.

Once in this mode, you can change the magnification (the zoom) of the axes by holding down the left mouse button and dragging the mouse over the axis (up and down for the y-axis, or right and left for the x-axis).

Configuration Menu

The Configuration menu has the following menu options:

- **Input Channel Configuration** – When you click this menu option or click the **Input Channel Configuration** toolbar button (), the **Configure Devices** dialog box appears. Using this dialog box, you can specify which input channels are sampled, and configure the sensor type, engineering units, number of millivolts per engineering unit, and the test point number for each channel.

Refer to [page 56](#) for more information about configuring the channels of your device.

- **Device Selection** – Opens the Device Selection window, allowing you to select the devices for use with QuickDAQ in acquisition mode. Refer to [page 17](#) for more information about using the Device Selection window.

Windows Menu

The Windows menu provides the following menu options:

- **Acquisition Config** window – Check this window option to show the Acquisition Config window. If this window option is unchecked, the Acquisition Config window is hidden. The Acquisition Config window allows you to configure the acquisition parameters of the data acquisition devices. Refer to [Chapter 4 starting on page 55](#) for more information on this window.
- **Plot and Data Config** window – Check this window option to show the Plot and Data Config window. If this window option is unchecked, the Plot and Data Config window is hidden. The Plot and Data Config window allows you to configure the appearance of the display. Refer to [Chapter 5 starting on page 87](#) for more information on this window.
- **Channel Plot** window – Check this window option to show the Channel Plot window. If this window option is unchecked, the Channel Plot window is hidden. This window allows you view the data from your device in a plot view. Refer to [page 41](#) and [page 94](#) for more information on this window.
- **Channel Display** window – Check this window option to show the Channel Display window. If this window option is unchecked, the Channel Display window is hidden. This window allows you view the data from your device in a digital display that resembles the front panel of the device. Refer to [page 52](#) and [page 88](#) for more information on this window.
- **Channel Statistics** window – Check this window option to show the Channel Statistics window. If this window option is unchecked, the Channel Statistics window is hidden. This window allows you view statistics about the data that you acquired. Refer to [page 53](#) for more information on this window.
- **Reset Window Layout to Last Saved** – Allows you to change the window layout to the last saved configuration.
- **Reset Window Layout to Default Layout** – Allows you to change the window layout to the default state.

Help Menu

The Help menu allows you to open this manual to describe the functionality of QuickDAQ, and get version information about the QuickDAQ application.

You can also open this manual using the **Help** toolbar button ().

Toolbar Buttons

The following buttons are provided on the toolbar:



-  – **New HPF Data File** – Creates a new (empty) data file for use with QuickDAQ. This is equivalent to using the **New Hpf Data file** menu option under the File menu, described on [page 25](#).

You can name and save the data file, as desired. The format of this file is High Performance binary (.hpf).

By default, the data file is stored in the following location:

For Windows Vista, Windows 7, or Windows 8:

C:\Users\<<username>\AppData\Local\Data Translation\QuickDAQ\Data

For Windows XP:

C:\Documents and Settings\<<user name>\Local Settings\Application Data\Data Translation\QuickDAQ\Data

-  – **Open HPF Data File** – Opens an .hpf data file that was created using QuickDAQ. This is equivalent to using the **Open Hpf Data file** menu option under the File menu, described on [page 25](#).

A sample data file, called QuickDAQ Data.hpf, is provided, by default, in the following location:

For Windows Vista, Windows 7, or Windows 8:

C:\Users\<<username>\AppData\Local\Data Translation\QuickDAQ\Data

For Windows XP:

C:\Documents and Settings\<<user name>\Local Settings\Application Data\Data Translation\QuickDAQ\Data

-  – **Export Data** – Opens the Export Data dialog box. This is equivalent to selecting the **Export Data** menu option of the File menu, described on [page 26](#).
-  – **Open Current Data in Excel** – After you stop recording, you can click this button to open a tab-separated (tmp.tvsv) file in Microsoft Excel that contains all the time domain data for the visible channels in the Channel Plot window.

You can then perform further analysis of your data using Excel or other utilities.

This is equivalent to selecting the **Open Current Data in Excel** menu option of the File menu, described on [page 28](#).

Note: Before using this option, ensure that Microsoft Excel is installed on your computer.

-  **Record** – **Record** – Starts data acquisition on the device and logs the data to a High Performance binary (.hpf) file. This is equivalent to selecting the **Start** menu option of the Record menu or pressing the **F5** key. You can specify the name of the data file using the **Recording** tab, described on [page 81](#).

Note: You can use the scrollbar on the x-axis to pause tracking and scroll back through the data to the beginning of acquisition. Refer to [page 44](#) and [page 46](#) for more information on pausing and resuming tracking.

For long duration acquisitions, ensure that your computer's power options are set to never hibernate; refer to [page 122](#) for more information.

-  **Pause** – **Pause** – Pauses recording. This is equivalent to selecting the **Pause** menu option of the Record menu or pressing the spacebar. To resume recording, click the **Pause** button, click the **Pause** menu option, or press the spacebar again.
-  **Stop** – **Stop** – Stops acquisition. This is equivalent to the **Stop** menu option under the **Record** menu or holding down the **Shift** key and pressing the **F5** key. You must stop acquisition to make configuration changes.
-  – **Input Channel Configuration** – Opens the Configure Devices dialog. This is equivalent to using the **Input Channel Configuration** menu option of the Configuration menu, described on [page 31](#).
-  **Style** – **Style** – Allows you to configure the theme colors used by the application. You can select one of the following theme colors:
 - Office 2010 Blue
 - Office 2010 Silver
 - Office 2010 Black
 - Visual Studio 2010
 - Windows 7
 - Office 2007 Blue
 - Office 2007 Black
 - Office 2007 Silver
 - Vista Glass
 - Custom Scheme – Allows you to select your own color scheme to use for the application.
-  – **Help** – Opens the this manual to describe QuickDAQ. This is equivalent to clicking the **User's Manual** menu option of the Help menu, described on [page 32](#).

Window Positioning

The configuration area of the interface contains the Acquisition Config and the Plot and Data Config windows. The display area of the interface contains the Channel Plot, Channel Display, and Channel Statistics windows. The Acquisition Status window is located under the Channel Plot, Channel Display, and Statistics windows.

This section describes how to move, resize, dock, and hide windows in the interface. The remaining sections of this document describe each window in more detail.

Moving, Resizing, and Docking Windows

Note: The Acquisition Status window is docked automatically. You cannot undock the Acquisition Status window.

You can move a window anywhere on the desktop by clicking the title bar or tab of the window and, while holding down the mouse button, dragging the window to the location you want. When you release the mouse button, this "floating" window remains in the location that you selected.


You can resize a window by clicking on any of the outside edges of the window and, while holding down the mouse button, dragging the window to the desired size. When you release the mouse, the window is scaled automatically.

You can also dock a window by doing the following:

1. Click the title bar or tab of the window.
2. Drag the window to where you want to dock it.
A guide diamond appears.

For windows in the configuration area, the four guides on the outside of the diamond represent the four sides of the configuration area. The center square docks the tabbed window in the configuration area. Additional guides are provided when you move the windows in the configuration area, allowing you to dock the window to the left side of the configuration area or to the right or left side of the display area.

For windows in the display area, the four guides on the outside of the diamond represent the four sides of the display area. The center square docks the tabbed window in the display area.



3. Move the pointer over the corresponding portion of the guide (the designated area is shaded), and release the mouse.

For example, if you want to dock the Acquisition Config window to the left side of the configuration area, drag the Acquisition Config window toward the middle of the configuration area, move the pointer over the guide on the far left, and then release the mouse button.

Notes: To return a window in the display area to its most recent docked location, press **CTRL** while you double-click the title bar of the window.

To dock/undock a window in the configuration area, press **CTRL** while you double-click the title bar of the window.

Hiding a Window

For all windows, except the Acquisition Status window, you can hide the window by clicking the "X" at the top, right corner of the window. To show the window again, click the **Windows** menu, and check the name of the window to show. Any window name that is not checked under the **Windows** menu is hidden.

You can hide the Acquisition Status window and the windows in the configuration area, if desired, by clicking the **Auto-Hide** pin () in the top, right corner of the window. When the window is hidden, a tab for the window is created; the size of the display area is increased. When the window is shown, the size of the display area is decreased. To see the window again, hover over the tab for the window. Click the **Auto-Hide** pin again to display the window.

Resetting the Window Layout

If you want to reset the windows to their default view, select the **Windows** menu, and select **Reset Window Layout to Default Layout**.

You can also reset the display area to its last saved configuration by selecting the **Windows** menu, and selecting **Reset Window Layout to Last Saved**.

Acquisition Config Window

The Acquisition Config window provides the following tabs for configuring recording and acquisition settings used by the device:

- **Recording tab** – This tab allows you to set up the file name for the data file, enable or disable continuous acquisition, and to specify the acquisition duration and x-axis span.

Refer to [page 81](#) for more information about using this tab to configure the recording settings.

The screenshot shows the 'Recording' tab of the Acquisition Config window. It features two tabs: 'Recording' (selected) and 'Acquisition'. The 'Recording' section includes:

- Filename generation:** A dropdown menu set to 'Filename-Sequence' and a 'Start #' field with the value '1'.
- Filename base:** A text field containing 'QuickDAQ Data', a file type dropdown set to '.hpf', and a browse button ('...').
- Path:** A text field showing the full file path: 'C:\Users\Nletoumeau\AppData\Local\Data Translation\QuickDAQ\Data\QuickDAQ Data-1.hpf'.
- Disk Space:** A label indicating '199438 MB available disk space'.
- Enable Continuous Acquisition:** An unchecked checkbox.
- Acquisition Duration:** A time selection dropdown set to '00:00:00:10' with a 'dd.hh:mm:ss' label.
- X Axis Span:** A time selection dropdown set to '00:00:00:10' with a 'dd.hh:mm:ss' label.
- Instructions:** A text prompt: 'Press the Record button to start recording data to disk.'
- Notes:** A large empty text area for user notes.

- **Acquisition tab** – This tab allows you to set up the parameters that apply to the analog input subsystem, including the per channel sampling frequency of the device, the trigger source that starts the acquisition, the channel configuration (single-ended or differential), input voltage range, the temperature units to use when converting voltage data to temperature, and/or the filter type. Refer to [page 83](#) for more information about using this tab to configure the acquisition settings.


The screenshot shows the 'Acquisition' tab of a software interface. It contains several configuration sections:

- Per Channel Sampling Frequency:** A text input field contains '195.3125' followed by 'Hz'. Below it, the range '(195.3Hz -105469Hz)' is displayed.
- Trigger Source:** A dropdown menu is set to 'Analog Threshold Neg Edge'.
- Threshold Trigger Options:** A sub-section containing:
 - Threshold value:** A text input field contains '0.15625' followed by 'V' and '(0.156V)'. Below it, the range '(-10 - 10 V)' is displayed.
 - Channel:** A dropdown menu is set to 'DT9837-C(00).Ain 0'.
- Single Ended/Differential:** A dropdown menu is set to 'SingleEnded'.
- Input Voltage Range:** A dropdown menu is set to '-10V to 10V'.
- Temperature Unit:** A dropdown menu is set to 'Celsius'.
- Filter Type:** A dropdown menu is set to 'None'.

Based on the information you set, the current sample rate, sample interval, and number of scans used by the device are displayed.

Plot and Data Config Window


The Plot and Data Config window allows you to select which channels you want to plot and specify the appearance of the display area. (Refer to [Chapter 5](#) for information about how to configure the settings of the Plot and Data Config window.)



Channel Plot Window

You can access the Channel Plot window by clicking the **Channel Plot** tab in the display area of the interface or by clicking the **Channel Plot** menu option under the **Windows** menu.


During acquisition, the results are plotted in the Channel Plot window in real time. In file-reader mode, the results are read from the file and plotted in the Channel Plot window.



The following sections describe how to set up the scaling for the y- and x-axes on the Channel Plot window, how to use the scrolling options for the Channel Plot window, and how to use the controls provided for the Channel Plot window. Refer to [Chapter 5](#) starting on [page 87](#) for more information about the Channel Plot window.

Setting Up the Y-Axis


If you right-click on the y-axis, the following dialog box is displayed:



These options are described below.

Y Axis Setup

If you select **Y Axis Setup**, the following dialog appears:



You can set up the following parameters for the y-axis:

- **Gridlines** – Select **Show Minor** if you want to display the minor gridlines on the y-axis; select **Show Major** if you want to display the major gridlines on the y-axis.
- **Scaling** – Select **Autoscale** if you want the application to determine the scale of the y-axis automatically. If you want to specify the scale of the y-axis, select **Manual** and then enter the minimum and maximum values for the y-axis.
- **Precision** – You can select the number of significant digits after the decimal point to display on the y-axis and in the cursor text; values range from 1 to 8 (2 is the default).

- **Format** – You can change for the format of the axis to see either the actual **Number** (such as 200) or the number in **Exponent** form (such as 2.0e+002).
- **Lin/Log** – If **Linear** scaling is selected for the channel, you can change the axis of the plotted data to either **Linear** or **Log10**.

Zoom to Fit in View


Select this menu option to scale the y-axis for the selected channel to the minimum and maximum values of the actual input signal(s) that are in the current view.

Zoom to Fit All

Select this menu option to scale the y-axis for the selected channel to the minimum and maximum values of the actual input signal(s) that were acquired, regardless of whether the data is in the current view.


Setting Up the X-Axis

If you right-click on the x-axis, the following dialog box is displayed:



X Axis Setup

If you select **X Axis Setup**, the following dialog appears:



You can set up the following parameters for the x-axis:

- **Gridlines** – Select **Show Minor** if you want to display the minor gridlines on the y-axis; select **Show Major** if you want to display the major gridlines on the y-axis.
- **Scaling** – Specify the scale of the x-axis by entering the minimum and maximum values for the x-axis.

Any options that are grayed out do not apply to this application.

Zoom to Fit All

Select this menu option to scale the x-axis for the selected channel to the minimum and maximum values of the actual input signal(s) that were acquired.

Edit Label

Select this menu option to change the text that is displayed for the x-axis.

Pause Tracking

If the application is recording, you can click this popup menu option to pause tracking for a specific plot. The plot stops updating, but data is still recorded to disk. The tracking for other plots is unaffected by this action.

A specific plot can also be paused by using the scrollbar for the x-axis to scroll through the data. After tracking is paused, the scrollbar continues to be updated so that you can scroll to the data as it is being acquired.

If you want to pause tracking for all channels, use the Tracking Pause  button on the toolbar instead. Refer to [page 46](#) for more information.

While tracking is paused, you can use the controls for the Channel Plot window, described on [page 46](#), to analyze the data that was previously recorded.


Resume Tracking

If recording is still in progress, you can resume tracking for a specific plot by clicking the Resume Tracking popup menu option. The tracking for other plots is unaffected.

To resume tracking for all plots whose tracking was paused, click the Tracking Resume  button on the toolbar. Refer to [page 46](#) for more information.

Scrolling Options

If you right-click on the scrollbar of the x-axis, the following dialog box is displayed:



The options are as follows:

- **Scroll Here** – Moves the scroll bar to the point of the mouse click that opened the scroll bar dialog.
- **Left Edge** – Moves the scroll bar to the left edge of the acquired data.
- **Right Edge** – Moves the scroll bar to the right edge of the acquired data.
- **Page Left** – Updates the content of the scroll area with the page of data to the left of the data is currently being displayed.
- **Page Right** – Updates the content of the scroll area with the page of data to the right of the data is currently being displayed.
- **Scroll Left** – Scrolls to the left.
- **Scroll Right** – Scrolls to the right.

Using the Channel Plot Window Controls

A toolbar, shown in [Figure 2](#), provides a number of controls for the Channel Plot window.



Figure 2: Toolbar of the Channel Plot Window

Tracking Resume

If the application is recording and tracking was paused, you can click this button to resume tracking for all plots on the display. The display is then updated with the current data in real time.

To resume tracking on a specific plot rather than on all plots, right-click the x-axis and select the Resume Tracking popup menu option; refer to [page 45](#) for more information.

Tracking Pause

If the application is recording, you can click this button to pause tracking on all plots of the display. The display stops updating, but data is still recorded to disk. While tracking is paused you can use the other controls to analyze the data that was previously recorded.

To pause tracking on a specific plot rather than on all plots, right-click the x-axis and select the Pause Tracking popup menu option or use x-axis scrollbar to scroll through the data; refer to [page 44](#).

Axes Scroll

When you click this button, you can scroll through the axes by holding down the left mouse button and dragging the mouse over the axis (up and down for the y-axis, or right and left for the x-axis).

If you want to change the magnification (zoom) of the axes while this button is selected, hold down the Ctrl button while holding down the left mouse button, and drag the mouse over the axis (up and down for the y-axis, or right and left for the x-axis).

When this button is selected, the Axes Zoom button is unselected.

Axes Zoom

When you click this button, you can change the magnification (the zoom) of the axes by holding down the left mouse button and dragging the mouse over the axis (up and down for the y-axis, or right and left for the x-axis).

When this button is selected, the Axes Scroll button is unselected.

Zoom-Out All 

When you click this button, the magnification of all axes is reduced (zoomed out) by a factor of 2.

Zoom-In All 

When you click this button, all axes are magnified (zoomed in) by a factor of 2.

Zoom All to Fit in View Y 

When you click this button, the scale of all y-axes are adjusted to the minimum and maximum values of the actual input signal(s).

Link X Axes to Selected 

Click the x-axis for the plot that you want to link to, then click the **Link X Axes** button to link all x-axes of the data. You can then use the scrolling controls to affect the view of all the x-axes of all the data at the same time.

Link Y Axes to Selected 

Click the y-axis for the plot that you want to link to, then click the **Link Y Axes** button to link all y-axes of the data. You can then use the scrolling controls to affect the view of all the y-axes of all data at the same time.

Link Cursors to Selected 

Locks data cursors together so that by moving the locked data cursor, all the data cursors move together. To use this button, click the **Data-Cursor** button, click the data cursor that you want to lock to, and then click the **Link Cursors to Selected** button. Once it is locked, moving the locked data cursor moves all the data cursors.

Select 

When you click this button, you can select items in the view area to zoom or scroll. This is equivalent to holding down the **Ctrl** and **Alt** keys while pressing the **V** key, or selecting the **Plot** menu, selecting **Plot Area Mouse Mode**, and choosing the **Select** menu option.

Zoom Box 

When you click this button, you can select a region in the view to magnify (zoom) by holding down the left mouse button, dragging the mouse to select the region that you want to magnify, and releasing the mouse button. The zoom action affects both axes.

This is equivalent to holding down the **Ctrl** and **Alt** keys while pressing the **Z** key, or selecting the **Plot** menu, selecting **Plot Area Mouse Mode**, and choosing the **Zoom** menu option.

Data-Cursor ▶◀

When you click this button, you can move the position of a data-cursor on the curve by holding down the left mouse button and dragging the mouse.

This is equivalent to holding down the **Ctrl** and **Alt** keys while pressing the **C** key, or selecting the **Plot** menu, selecting **Plot Area Mouse Mode**, and choosing the **Cursor** menu option.


When the **Data-Cursor** is active, right-click the mouse to change the cursor style, line style, and/or color of the cursor; the following menu appears:



You can change the cursor style to one of the following settings:

- **Value-XY** – Choose this style to display a single value at a particular point on the X- and Y-axes.
- **Period** – Choose this style to display the period, in seconds, between two vertical cursors. You can drag each cursor independently.
- **Frequency** – Choose this style to display the frequency, in Hertz, between two vertical cursors. You can drag each cursor independently.
- **Peak-Peak** – Choose this style to display the value between two horizontal cursors. This is the number of volts or sensor units. You can drag each cursor independently.

The following example shows a period data cursor, where two data cursors show the period, in seconds, between two data points:



You can change the line style to one of the following settings:

- **Solid** – Choose this style to display the cursors as solid lines.
- **Dash** – Choose this style to display the cursors as a dashed lines.
- **Dot** – Choose this style to display the cursors as a dotted lines.
- **DashDot** – Choose this style to display the cursors as lines of dash-dot elements.

You can change the color of the cursors to one of the provided basic colors or to any custom color you desire.

Copy to Clipboard

When you click this button, you can copy either the graph (the picture) or the data that is displayed in the Channel Plot window to the clipboard.

Save Plot Image

When you click this button, you can save the image from the Channel Plot window to a file. Specify the name of the file and choose one of the extensions to save the file as a graphic.

The default location for saving the image files is as follows:

For Windows Vista, Windows 7, or Windows 8:

C:\Users\\AppData\Local\Data Translation\QuickDAQ\Data.

For Windows XP:

C:\Documents and Settings\\Local Settings\Application Data\Data Translation\QuickDAQ\Data

Print

When you click this button, you can print the picture from the Channel Plot window to a printer.

Preview

When you click this button, you can preview the image from the Channel Plot window before you print it.

Page Setup

When you click this button, you can configure the page before you print it. Options are available for configuring the size, orientation, and margins of the page.

Show Legend

When you click this button, you can show or hide the legend that defines the colors used for each channel on the plot. An example follows:




Show Data Point Markers

When you click this button, you can show or hide markers that indicate the actual samples on the curve, as shown in the following example. The diamond markers indicate the actual samples.

If you click on a data point marker, a label for the channel is displayed.


Note: When moving the data-cursor with the data point markers shown, the data-cursor snaps to the closest sample on the curve.



Channel Display Window

You can access the Channel Display window by clicking the **Channel Display** tab in the display area of the interface or by clicking the **Channel Display** menu option under the **Windows** menu.


During acquisition, the newest value for each enabled channel is displayed in the Channel Display window in real time. The Channel Display window allows you to view data from your device in a digital display. By default, the layout represents the channel locations on the front panel of the device. Refer to [Chapter 5](#) starting on [page 87](#) for more information about the Channel Display window.



Statistics Window

You can access the Statistics window by clicking the **Statistics** tab in the display area of the interface or by clicking the **Channel Statistics** menu option under the **Windows** menu.


During acquisition, the statistics are displayed in the Statistics window in real time, providing that the channel statistics were made visible in the Plot and Data Config window, described on [page 105](#). The Statistics window shows the minimum, maximum, and mean values of the data, along with the standard deviation for each enabled channel.



Ch #	Channel	Min	Max	Mean	Std Dev
0	192.43.218.153.RTD.0	23.14949036	23.15640831	23.15264221	0.00180182
1	192.43.218.153.MR.8	-0.00001454	0.00001388	0.00000009	0.00000681

Acquisition Status Window

The Acquisition Status window, located under the Channel Plot, Channel Display, and Statistics windows, shows the status of the device.





Configuring Channels and the Acquisition Settings

Configuring Channels of a Device.....	56
Configuring the Settings of the Recording Tab	81
Configuring the Settings of the Acquisition Tab	84

Configuring Channels of a Device

Notes: To configure the channels, you must have selected a supported device or have opened an .hpf file that contains configuration settings for a supported device.

If acquisition is in progress, you must choose **Stop** from the **Record** menu or click the **Stop** toolbar button () before you can change the configuration of a device.

Choose the **Input Channel Configuration** toolbar button () or the **Input Channel Configuration** from the **Configuration** menu to configure the channels from which to acquire data in the analog input data stream. The Configure Devices dialog appears.

The elements of the Configure Devices dialog depend on the specified device. For example, the Configure Devices dialog for a MEASURpoint instrument appears as follows:




Figure 3: Example Configuration of a MEASURpoint Instrument

In contrast, the Configure Devices dialog for a DT9836 module appears as follows:




Figure 4: Example Configuration of a DT9836 Module

Enabling Channels

Select the channels that you want to enable for acquisition by clicking the checkbox under the **Enable** column. Only data from the enabled channels is included in the analog input data stream.

Note: For the DT9805 and DT9806 modules, the CJC channel is enabled automatically if any of the analog input channels are configured for a temperature sensor type. You can disable this channel, if desired.

If you want to enable all the channels at once, click the **Multi-channel Actions** button ( **Actions** ▾) and then click **Enable all Channels**. If you want to enable several but not all channels at once, highlight the channels that you want to enable, click the **Multi-channel Actions** button, and then click **Enable all Selected Channels**.

If you want to disable all the channels at once, select the **Multi-channel Actions** button, and then click **Disable all Channels**. If you want to disable several but not all channels at once, highlight the channels that you want to disable, click the **Multi-channel Actions** button, and then click **Disable all Selected Channels**.

Channel Name

For each channel, you can specify a meaningful name for each channel, if desired, by highlighting the channel under the **Channel Name** column and entering a new name.

Analog Input Channel Settings for Devices that Support Temperature and/or Multi-Range Voltage Inputs

This section describes the analog input settings that you can configure for devices, such as the MEASURpoint instruments and DT9805/DT9806 modules, that support temperature and/or multi-range voltage input channels.

Sensor Type

Select the type of sensor that is connected to each channel under Sensor Type column. Values are as follows:

For devices that support thermocouple input types for each channel:

- Type B
- Type E
- Type J
- Type K
- Type N

- Type R
- Type S
- Type T
- Volts

If you want to specify the same thermocouple type for all channels, click the **Multi-channel Actions** button ( **Actions** ▾), select **Set all Thermocouple Channels**, and select the specific thermocouple type.

For devices that support RTD input types for each channel:

- Euro PT1000 (for 2- and 4-wire RTDs)
- Euro PT500 (for 2- and 4-wire RTDs)
- Euro PT100 (for 2- and 4-wire RTDs)
- American PT1000 (for 2- and 4-wire RTDs)
- American PT500 (for 2- and 4-wire RTDs)
- American PT100 (for 2- and 4-wire RTDs)
- Euro PT1000 3 Wire (for 3-wire RTDs)
- Euro PT500 3 Wire (for 3-wire RTDs)
- Euro PT100 3 Wire (for 3-wire RTDs)
- American PT1000 3 Wire (for 3-wire RTDs)
- American PT500 3 Wire (for 3-wire RTDs)
- American PT100 3 Wire (for 3-wire RTDs)
- Ohms
- Volts

If you want to specify the same RTD type for all channels, click the **Multi-channel Actions** button ( **Actions** ▾), select **Set all RTD Channels**, and select the specific RTD type.

For devices that support multi-range voltage inputs per channel:

- ± 10 V, ± 100 V, or ± 400 V for DT8874, DT9847, DT8873, and DT9873 instruments
- ± 10 V, ± 100 V, or ± 600 V for DT8875 instruments
- ± 100 mV, ± 1.0 V, or ± 10 V for DT8876 instruments
- ± 10 V, ± 1.25 V, ± 0.625 V, or ± 0.3125 V for DT8824 instrument modules
- ± 600 V, ± 75 V, ± 37.5 V, or ± 18.75 V for DT8824-HV instrument modules

If you want to specify the same voltage range for all multi-range channels, click the **Multi-channel Actions** button ( **Actions** ▾), select **Set all Multi-Range Channels**, and select the specific voltage range.

Check the user's manual for your device for more information on supported sensor types.


Range

If supported, set the input range for each analog input channel.

Engineering Unit (EU)

Depending on the sensor that is connected to each analog input channel, you can select the following engineering units:

- For channels that are configured for thermocouple or RTD inputs, the data is returned in **Deg C**, **Deg F**, or **Deg K**. Note that you determine whether the data is returned in degrees C, degrees F, or degrees K using the **Acquisition** tab, described on [page 84](#).
- For voltage inputs, you can choose from one of the following engineering units to display the data, based on the sensor that is attached to the channel:



If you select **Custom**, you can define your own engineering units.

If you want to specify the same engineering units for all voltage channels, click the **Multi-channel Actions** button ( **Actions** ▾), select **Set all Voltage Channel Units**, and select the specific engineering units to use from the list above.

If you want to set the engineering units for some but not all analog input channels at once, select the **Multi-channel Actions** button, click **Set all Selected Channel Units**, and select the desired engineering units.

mV/EU

If the sensor type is Volts, you can enter the number of millivolts per engineering unit (mV/EU) by which to scale the raw voltage based on the engineering units that you selected.

EU Offset

You can enter an offset (EU Offset) value to add to the scaled signal.

Point #

If desired, you can enter a number representing the test point to which this channel corresponds. By default, values start at 1 and increment with each channel.

Analog Input Channel Settings that Support IEPE Inputs

This section describes the settings that you can configure for devices, such as the DT8837, DT9837 Series, and DT9847 Series devices, that support IEPE inputs on the analog input channels.

Range

Set the input range for each analog input channel.

Coupling Type

Select **AC** (AC coupling) to remove any DC offset from your measurement, or select **DC** (DC coupling) if the signal source has no offset voltage or if the DC content of the acquired signal is important. Most IEPE input signals require AC coupling.

If you want to set the coupling type for all analog input channels at once, select the **multi-channel Actions** button (), click **Set all Channel Coupling**, and select either **AC** or **DC**.


Current Source

Enable use of the 4 mA current source by checking the **Current Source** checkbox, or disable use of the 4 mA current source by unchecking the **Current Source** checkbox. Most IEPE input signals require use of the current source.


If you want to set the current source for all analog input channels at once, select the **multi-channel Actions** button (), click **Set all Channel Current Source**, and select either **Enabled** or **Disabled**.

Engineering Unit (EU)

You can choose from one of the following engineering units to represent the data, based on the sensor that is attached to the channel:



If you select **Custom**, you can define your own engineering units.

If you want to set the engineering units for all analog input channels at once, select the **Multi-channel Actions** button(), click **Set all Channel Units**, and select the desired engineering units.

If you want to set the engineering units for some but not all analog input channels at once, select the **Multi-channel Actions** button(), click **Set all Selected Channel Units**, and select the desired engineering units.

mV/EU

Depending on the engineering units that you selected, you can enter the number of millivolts per engineering unit (mV/EU) by which to scale the raw voltage.

EU Offset

Depending on the engineering units that you selected, you can enter an offset (EU Offset) value to add to the scaled signal.

Point #

If desired, you can enter a number representing the test point to which this channel corresponds. By default, values start at 1 and increment with each channel.

Dir


Specify one of the following sensor directions for the analog input channel, if desired: X+, X-, Y+, Y-, Z+, Z-, or Scalar (no direction).

Analog Input Channel Settings for Devices that Support Voltage

This section describes the settings that you can configure for the analog input channels on your device.

Engineering Unit (EU)

For voltage inputs, you can choose from one of the following engineering units to display the data, based on the sensor that is attached to the channel:



If you select **Custom**, you can define your own engineering units.

If you want to specify the same engineering units for all voltage channels, click the **Multi-channel Actions** button ( **Actions** ▾), select **Set all Voltage Channel Units**, and select the specific engineering units to use from the list above.

If you want to set the engineering units for some but not all analog input channels at once, select the **Multi-channel Actions** button, click **Set all Selected Channel Units**, and select the desired engineering units.

mV/EU

Enter the number of millivolts per engineering unit (mV/EU) by which to scale the raw voltage based on the engineering units that you selected.

EU Offset

You can enter an offset (EU Offset) value to add to the scaled signal.

Point #

If desired, you can enter a number representing the test point to which this channel corresponds. By default, values start at 1 and increment with each channel.

Analog Input Channel Settings for Devices that Support Strain

This section describes the settings that you can configure for the analog input channels on devices, such as the DT9838, that support strain.

Enable Shunt Resistor


For quick verification of your wiring, you can enable the internal shunt resistor, acquire data, and then verify that you are measuring the value that you expect from your strain gage. (Be sure to disable the shunt resistor after you have verified your wiring.)

Note that this use of the shunt resistor is different from the use of the shunt resistor when performing shunt calibration. Shunt calibration is done using the Configuration and Calibration wizard, described next. During shunt calibration, the software automatically enables the shunt resistor for the calibration procedure and disables it once calibration has been performed.

Configuration and Calibration Wizard

You can use the **Configuration and Calibration** wizard to set up the parameters for the strain gage or bridge-based sensor and, if desired, calibrate it.

When you click the **Configure and Calibrate** button, a screen similar to the following is displayed:



Select the type of sensor that is connected to the selected channel. The following choices are available:

- **Full Bridge Based Sensor** – for load cells, pressure transducers, torque transducers, and other bridge-based sensors
- **Strain Gage** – for strain gage sensors
- **Voltage Based Sensor** – for voltage inputs or non-strain gage inputs

If your bridge-based sensor or strain gage supports TEDS (Transducer Electronic Data Sheet) data in hardware, the LED on this screen turns green. Click the **Apply TEDs Values** button to apply the TEDS data to the channel configuration.

If your sensor does not support TEDS data in hardware, the LED on this screen turns red. If a TEDS data file (virtual TEDS) is available for your sensor, click the **Open TEDs data file....** button, select the TEDS data file to read, and click **Open**. The TEDS values are applied to the channel configuration.

Click **Next** to continue to the next page of the wizard.

Parameters for Full Bridge Based Sensors

If you select **Full Bridge Based Sensor** as your sensor type, a screen similar to the following appears:

VF Configuration and Calibration Wizard
Full Bridge Based Sensor Configuration
 Channel Ain 0

Transducer Rated Output: 2 mV/V nominal

Transducer Capacity: 1000 µε

Using Sense Lines: No

Lead Wire Resistance: 0 Ohms

Excitation Voltage: 5 Volts (all channels)

Nominal Gage: 120 Ohms

Unit: µε

< Back Next > Cancel


If you applied TEDS values from the sensor hardware or data file, the TEDS values are displayed in the fields on this screen.

You can configure the following parameters:

- **Transducer Rated Output** – Specify the rated output of the transducer in terms of mV/V excitation.
- **Transducer Capacity** – Specify the full-scale range of the transducer in its native engineering units.
- **Using Sense Lines** – For the selected analog input channel, enter **Yes** if remote sense lines are used or **No** if remote sense lines are not used in the wiring of the strain gage to the device.


The wiring diagram changes depending on this selection. To see the wiring diagram of the strain gage to the device, click the  button.

- **Lead Wire Resistance** – For the selected analog input channel, specify the lead wire resistance, in ohms. Note that if remote sense lines are used, then this value is set to 0 automatically.
- **Excitation Voltage** – Specify the value of the excitation voltage that will be applied to all analog input channels on the device.
- **Nominal Gage** – For the selected analog input channel, enter the nominal gage resistance, in ohms, that is specified by the manufacturer of the sensor.
- **Unit** – For the selected analog input channel, select one of the following engineering units to represent the data, based on the sensor that is attached to the channel:



If you select **Custom**, you can define your own engineering units.


Click **Next** to continue to the calibration page of the wizard. A screen similar to the following appears:



A balanced bridge produces zero volts under ideal conditions with zero strain applied. In practice, however, the output of a bridge in an unstrained condition is offset from zero slightly due to imperfect matching of bridge resistances.

You can adjust the offset of the channel by performing offset nulling on the channel. To perform offset nulling, select the **Offset Nulling** checkbox, click **Next**, and then click **Calibrate**. Internally, this value is subtracted from all subsequent measurements before the voltage is converted to the selected engineering units. Note that you wish, you can reset the value by clicking the **Reset** button.

You can use shunt calibration to correct span errors in the measurement path. To perform shunt calibration, select the **Shunt Calibration** checkbox, and click **Next**. A screen similar to the following appears:



If you want to enter a value rather than use a shunt resistor to perform the shunt calibration procedure, select **Physical Value** as the **Calibration Type**. The page changes to allow you to enter a value. Enter the physical value to apply to the bridge, and click the **Calibrate** button.

To use the internal shunt calibration resistor provided by the device to perform shunt calibration, do the following:

1. Select **Shunt Resistor** as the **Calibration Type**.
2. Select **Internal** for the **Select Resistor Source** combo box.
3. Ensure that the internal RSHUNT+ and RSHUNT- lines are connected across the gage and that no strain is applied to the specimen. (The internal shunt resistor is automatically enabled for this procedure and automatically disabled when the shunt calibration procedure is complete.)
4. For the **Select Node to Shunt** combo box, select the node (R1 to R4) that you want to shunt.
5. Click the **Calibrate** button.

If you want to use an external shunt calibration resistor to perform shunt calibration, do the following:

1. Select **Shunt Resistor** as the **Calibration Type**.
2. Select **External** for the **Select Resistor Source** combo box.
3. Ensure that the external shunt resistor is connected across the gage, and that no strain is applied to the specimen.
4. For the **Select Node to Shunt** combo box, select the node (R1 to R4) that you want to shunt.
5. Click the **Calibrate** button.

The calculated value, measured value, and correction coefficient are displayed. Note that you wish, you can reset the values by clicking the **Reset** button.

Click **Finish** when you are done using the wizard.

Parameters for Strain Gage Sensors

If you select a **Strain Gage** sensor, a screen similar to the following appears:

VF Configuration and Calibration Wizard

Strain Gage Configuration
Channel Ain 0

Bridge Type: **Quarter Bridge** Excitation Voltage: **5** Note: This value will be set for all channels.

Circuit Diagram: A quarter bridge circuit with an excitation voltage V_{EX} connected to a bridge of resistors R_1 , R_2 , R_3 , and R_4 . A load resistor R_L is connected across R_4 . A voltmeter V_o is connected across R_3 and R_4 .

Parameters:

Nominal Gage	Using Sense Lines	Min Range	Unit
120 Ohms	No	-1000 $\mu\epsilon$	$\mu\epsilon$
Gage Factor	Lead Wire Resistance	Max Range	Poisson Ratio
2	0 Ohms	1000 $\mu\epsilon$	0.32

< Back Next > Cancel

If you applied TEDS values from the sensor hardware or data file, the TEDS values are displayed in the fields on this screen.

You can configure the following parameters:


- **Bridge Type** – Select one of the following bridge configurations for each analog input channel; refer to the user’s manual for your device for more information about each of these configuration types:
 - Quarter Bridge
 - Quarter Bridge Temp Comp
 - Full Bridge Axial Poisson
 - Full Bridge Bending
 - Full Bridge Bending Poisson
 - Half Bridge Bending
 - Half Bridge Poisson

A circuit diagram is shown for the selected configuration type. To see how to wire the strain gage to the device, click the  button.

- **Excitation Voltage** – Specify the value of the excitation voltage that will be applied to all analog input channels on the device.
- **Nominal Gage** – For the selected analog input channel, enter the nominal gage resistance, in ohms, that is specified by the manufacturer of the strain gage.
- **Gage Factor** – For the selected analog input channel, enter the gage factor that is specified by the manufacturer of the strain gage.
- **Using Sense Lines** – For the selected analog input channel, enter **Yes** if remote sense lines are used or **No** if remote sense lines are not used in the wiring of the strain gage to the device.

The wiring diagram changes depending on this selection. To see the wiring diagram of the strain gage to the device, click the  button.

- **Lead Wire Resistance** – For the selected analog input channel, specify the lead wire resistance, in ohms. Note that if remote sense lines are used, then this value is set to 0 automatically.
- **Min Range** – For the selected analog input channel, specify the minimum strain value for the range.
- **Max Range** – For the selected analog input channel, specify the maximum strain value for the range.
- **Unit** – For the selected analog input channel, select one of the following engineering units to represent the data, based on the sensor that is attached to the channel:




If you select **Custom**, you can define your own engineering units.

- **Poisson Ratio** – Depending on the bridge type, specify the Poisson ratio for each analog input channel. If you click the  button, the following Poisson ratios are displayed for various materials:


Material	Poisson's ratio
rubber	~ 0.50
gold	0.42
saturated clay	0.40-0.50
magnesium	0.35
titanium	0.34
copper	0.33
aluminium-alloy	0.33
clay	0.30-0.45
stainless steel	0.30-0.31
steel	0.27-0.30
cast iron	0.21-0.26
sand	0.20-0.45
concrete	0.20
glass	0.18-0.3
foam	0.10-0.40
cork	~ 0.00

Click **Next** to continue to the calibration page of the wizard. A screen similar to the following appears:




A balanced bridge produces zero volts under ideal conditions with zero strain applied. In practice, however, the output of a bridge in an unstrained condition is offset from zero slightly due to imperfect matching of bridge resistances.

You can adjust the offset of the channel by performing offset nulling on the channel. To perform offset nulling, select the **Offset Nulling** checkbox, and click **Next**. A screen similar to the following appears:



Click **Calibrate**. Internally, the calibrated offset is subtracted from all subsequent measurements before the voltage is converted to strain. Note that you wish, you can reset the value by clicking the **Reset** button.

You can use shunt calibration to correct span errors in the measurement path. To perform shunt calibration, select the **Shunt Calibration** checkbox, and click **Next**. A screen similar to the following appears:



If you want to use the internal shunt calibration resistor provided by the device, select **Internal** for the **Select Resistor Source** combo box, ensure that the internal RSHUNT+ and RSHUNT- lines are connected across the gage, and that no strain is applied to the specimen. (The internal shunt resistor is automatically enabled for this procedure and automatically disabled when the shunt calibration procedure is complete.) Then, for the **Select Node to Shunt** combo box, select the node that you want to shunt (the values depend on the bridge type that you selected).


If you want to use a user-supplied external shunt calibration resistor, select **External** for the **Select Resistor Source** combo box, ensure that the external shunt resistor is connected across the gage, and that no strain is applied to the specimen. Then, for the **Select Node to Shunt** combo box, select the node that you want to shunt (the values depend on the bridge type that you selected).

Once the shunt calibration parameters have been configured, click **Calibrate**. The calculated value, measured value, and correction coefficient are displayed. Note that you wish, you can reset the values by clicking the **Reset** button.

Click **Finish** when you are done using the wizard.


Parameters for Voltage Based Sensors

If you select **Voltage Based Sensor** as your sensor type, a screen similar to the following appears:



You can configure the following parameters:

- **Unit** – You can choose from one of the following engineering units to represent the data, based on the input that is attached to the channel:



If you select **Custom**, you can define your own engineering units.

- **Sensor Scaling** – Depending on the engineering units that you select, you can enter the number of millivolts per engineering unit (mV/EU) by which to scale the raw voltage.
- **Sensor Offset** – Depending on the engineering units that you select, you can enter an offset value to add to the scaled signal.

Click **Finish** when you are done using the wizard.

Point #

If desired, you can enter a number representing the test point to which this channel corresponds. By default, values start at 1 and increment with each channel.

Tachometer Settings

This section describes the settings that you can configure for tachometer channels that are supported in the analog input data stream.

Engineering Unit (EU)

For each tachometer channel, you can choose from one of the following engineering units to plot the data:

- **RPM** – Choose **RPM** if you want to plot the data from the tachometer in RPMs.
- **Sec** – Choose **Sec** if you want to plot the data from the tachometer in seconds.
- **Hz** – Choose **Hz** if you want to plot the data from the tachometer in Hertz.

Ticks/Rev

When you select **RPM** as the engineering unit for the tachometer, enter the number of ticks per revolution for your particular tachometer in the **Ticks/Rev** field. This allows the application to calibrate to the characteristics of your tachometer.

Max RPM

When you select **RPM** as the engineering unit for the tachometer, enter the maximum number of revolutions per minute for your particular tachometer in the **Max RPM** field.

This allows the application to calibrate to the characteristics of your tachometer.

RPM Multiplier

When you select **RPM** as the engineering unit for the tachometer, you can enter a value in the **RPM Multiplier** field to convert RPM into other units, such as Miles per Hour, Revolutions Per Second, or Hz. For example, to multiply by a factor of 2, enter 2 in the **RPM Multiplier** field. To divide by 2, enter a value of 0.5 in the **RPM Multiplier** field.

Max mSec/Hz

When you select **Sec** or **Hz** for the engineering units of the tachometer, you can enter the maximum value for the Y-axis in the **Max mSec/Hz** field.

Tach Edge

On the DT9837, the period of the tachometer input signal is not programmable; it is always measured from rising-to-rising edge. For other devices, select which period of the tachometer input signal to measure:

- **Rising** – Measures from the rising-to-rising edge of the tachometer input signal.
- **Falling** – Measures from the falling-to-falling edge of the tachometer input signal.

Note: Old tachometer values (from a previous tachometer operation) may be in the data stream until two tachometer edges of the specified type are detected.

Counter Settings

This section describes the settings that you can configure for counters that are supported in the analog input data stream.

Note that counters may be used differently depending on the device. For example, [Table 1](#) describes how the counters are used the DT9837 Series devices. Refer to the documentation for your device for information on the counters provided by your device.

Table 1: Use of Counter 1 and Counter 2 on Each Device

Device	Counter 1 (Tach Counter)	Counter 2 (Gate Counter)
DT8837	Measure the frequency, period, or phase between two specified signals.	Measure the frequency, period, or phase between two specified signals.
DT9837	Not supported.	Not supported.
DT9837A	Measures the phase of the tachometer signal.	Not accessible on the device.
DT9837A-OEM	Measures the phase of the tachometer signal.	Measures the pulse width of the gate input signal or the phase between the gate signal and the A/D completion signal.
DT9837B	Measures the phase of the tachometer signal.	Measures the pulse width of the gate input signal or the phase between the gate signal and the A/D completion signal.
DT9837C	Not supported.	Not supported.
DT9838	Measure the frequency or period of the tachometer input signal.	Not supported.

Engineering Unit (EU)

For each counter, you can choose from one of the following engineering units to plot the data:

- **Sec** – Choose Sec if you want to plot the data from the counter in seconds.
- **Hz** – Choose Hz if you want to plot the data from the counter in Hertz.
- **Counts** – Some devices provide the **Counts** option. Choose **Counts** if you want to plot the number of counts that were counted by the counter/timer.

Max mSec/Hz

When you select **Sec** or **Hz** for the engineering units of the counter, you can enter the maximum value for the Y axis in the **Max mSec/Hz** field.

Start Edge

For each supported counter, select the signal edge that will start the measurement. You can choose from the following signals (note that not all options are provided by all devices):

- **A/D Complete**
- **Tach Rising** (on the DT9837 Series, this is supported by the Tach Counter only)
- **Tach Falling** (on the DT9837 Series, this is supported by the Tach Counter only)
- **Clock Rising**
- **Clock Falling**
- **Gate Rising** (on the DT9837 Series, this is supported on the Gate Counter only)
- **Gate Falling** (on the DT9837 Series, this is supported by the Gate Counter only)

Stop Edge

For some devices, you can specify the stop edge of the counter, which stops the measurement. You can choose from the following signals:

- **A/D Complete**
- **Tach Rising** (on the DT9837 Series, this is supported by the Tach Counter only)
- **Tach Falling** (on the DT9837 Series, this is supported by the Tach Counter only)
- **Gate Rising** (on the DT9837 Series, this is supported on the Gate Counter only)
- **Gate Falling** (on the DT9837 Series, this is supported by the Gate Counter only)

Quadrature Decoder Channel Settings

This section describes the settings that you can configure for quadrature decoder channels that are supported in the analog input data stream.

Engineering Unit (EU)

For each counter, you can choose from one of the following engineering units to plot the data:

- **Deg** – Choose **Deg** if you want to plot the data from the quadrature decoder in degrees.
- **Counts** – Choose **Counts** if you want to plot the number of counts that were counted by the quadrature decoder.

Pulses/Rev

Enter the number of pulses per revolution for your quadrature encoder. This number is device-specific; therefore, refer to the documentation for your quadrature encoder to determine this number.

Clock Prescale

Enter the pre-scale value that is used to filter the onboard clock. Using a clock pre-scale value can remove ringing edges and unwanted noise for more accurate data.

X4 Scaling

The scaling mode (X1 or X4 mode), determines the resolution of the quadrature encoder. If X4 Scaling is disabled, X1 mode is used. In X1 mode, the quadrature decoder counts the edges on the A signal input.

If X4 scaling mode is enabled, X4 scaling mode is used. In X4 mode, the quadrature decoder counts the edges on the A and B signal inputs. Therefore, if a quadrature encoder has 360 pulses per revolution, X1 mode yields 360 counts when the quadrature encoder is rotated 360 degrees. X4 mode yields four times the number of counts, or 1440 (360 x 4) when the quadrature encoder is rotated 360 degrees.

Index Mode

You can specify one of the following for the **Index Mode**:

- **High** – The Index input is enabled and the positional count is zeroed on the high edge of the Index signal.
- **Low** – The Index input is enabled and the positional count is zeroed on the low edge of the Index signal.
- **Disabled** – The Index input is disabled and the positional count is not zeroed. Note that if **X4 Scaling** is Enabled, **Index Mode** must be disabled.

Applying and Saving Changes


Click **Close** when you are through with this dialog box to apply the changes you made to the hardware and to reconfigure the application, as needed.


For information on saving and loading a configuration file, refer to [page 28](#). For information about the backup configuration file, refer to [page 29](#).

Configuring the Settings of the Recording Tab

Before starting acquisition, configure how the data is recorded using the Recording tab of the Acquisition Config window:

The recording settings are described as follows:

- **Filename generation** – Specify how to create the name of the file. You can choose one of the following options:
 - **Filename** – The specified filename is created when you click the **Record** toolbar button (). Each time you click the **Record** toolbar button, you will be prompted to overwrite the file. QuickDAQ Data.hpf is an example of a filename that was created using the Filename option.
 - **Filename-Sequence** – The specified filename is created and a starting number that you define is appended to the filename when you click the **Record** toolbar button (). Each time you click the **Record** toolbar button, the number that is appended to the filename is incremented by one. QuickDAQ Data-1.hpf is an example of a filename that was created using the Filename-Sequence option.

- **Filename-DateTime** – The specified filename is created and the current date and time is appended to the filename when you click the **Record** toolbar button (). Each time you click the **Record** toolbar button, the filename with the current date and time is created. QuickDAQ Data-2012-11-15_02-15-31-PM.hpf is an example of a filename that was created using the **Filename-DateTime** option.
- **Filename base** – Specify the name of the High Performance binary file (.hpf) in which to store the data that is recorded when you click the **Record** toolbar button (). The default path is shown. You can change this path, if desired. The application saves the data file path and uses this path by default.
- **Enable Continuous Acquisition** – Determines how data acquisition and processing stops. Check this checkbox to enable continuous acquisition. In this mode, you must click the **Stop** button or hold down the **Shift** key and press the **F5** key to stop acquisition/processing.
If the **Enable Continuous Acquisition** checkbox is unchecked, you must specify how long to acquire data using the **Acquisition Duration**.
- **Acquisition Duration** – (Available only if the **Enable Continuous Acquisition** checkbox is unchecked). You can either enter a value that specifies the number of days (dd), number of hours (hh), minutes (mm), and seconds (ss) that you want to acquire data from the device, or select one of the following predefined values from the combo box:
 - 10 Seconds
 - 1 Minute
 - 5 Minutes
 - 10 Minutes
 - 30 Minutes
 - 1 Hour
 - 5 Hours
 - 12 Hours
 - 1 Day
 - 2 Days

If the **Enable Continuous Acquisition** checkbox is unchecked, acquisition stops automatically when the specified duration elapses.

- **X Axis Span** – You can either enter a value that specifies the number of days (dd), number of hours (hh), minutes (mm), and seconds (ss) that you want to use for the span of the x-axis of the plots on the Channel Plot window, or select the default value from the combo box.

Note: If you specify a value for the x-axis span that is less than the acquisition duration, the x-axis scrolls using the span you specified.


- **Notes** – Use this field to add any notes as desired. If you choose to export the data to ASCII, this information is also exported.

Based on the information that you enter for the **Recording** tab and the **Acquisition** tab, the software configures the hardware and displays the following configuration settings used by the device:

- The actual sample rate used by the device.
- The actual sample interval used by the device.
- The actual number of scans to acquire.

Configuring the Settings of the Acquisition Tab

Use the **Acquisition** tab of the Acquisition Config window to set up parameters that apply to the A/D subsystem of the device, including the sampling frequency, trigger source, filter type, temperature units, channel configuration, and/or input voltage range.



The screenshot shows the 'Acquisition' tab of a configuration window. The settings are as follows:

- Per Channel Sampling Frequency:** 195.3125 Hz (range: 195.3Hz - 105469Hz)
- Trigger Source:** Analog Threshold Neg Edge
- Threshold Trigger Options:**
 - Threshold value:** 0.15625 V (0.156V) (range: -10 - 10 V)
 - Channel:** DT9837-C(00).Ain 0
- Single Ended/Differential:** SingleEnded
- Input Voltage Range:** -10V to 10V
- Temperature Unit:** Celsius
- Filter Type:** None

Sampling Frequency

Enter the sampling frequency per channel for the device. For simultaneous devices, the total throughput is the same as the per channel sampling frequency, since all channels are acquired at the same time.

For multiplexed devices, multiply the per channel sampling frequency by the number of enabled channels to determine the total throughput. For example, if five analog input channels are enabled on the multiplexed device and the per channel sampling frequency is 200 Hz, the total throughput is 1000 Hz (200 Hz x 5).

Refer to the user's manual for your device for information on the supported sampling frequencies.

Trigger Source

Specify the trigger source that starts acquisition on the device. Examples of trigger sources that may be supported for starting acquisition on the device include the following:

- **Software** – The device starts acquiring scans when you click the **Record** button or press the **F5** key. Once acquisition starts, all triggers are ignored. Acquisition stops when the conditions defined in the **Recording** tab, described on [page 81](#), are met.
- **External TTL Pos Edge** – The device starts acquisition when it detects a rising-edge voltage on the external trigger line. Once triggered, the state of external trigger line is ignored. The process continues until the conditions defined in the **Recording** tab, described on [page 81](#), are met.
- **External TTL Neg Edge** – The device starts acquisition when it detects a negative-edge voltage on the external trigger line. Once triggered, the state of external trigger line is ignored. The process continues until the conditions defined in the **Recording** tab, described on [page 81](#), are met.
- **Analog Threshold Pos Edge** – The device starts acquisition when it detects a positive edge, analog threshold trigger event. You can specify the threshold value on which to trigger and the channel to use for the analog threshold trigger.
- **Analog Threshold Neg Edge** – The device starts acquisition when it detects a negative edge, analog threshold trigger event. You can specify the threshold value on which to trigger and the channel to use for the analog threshold trigger.

For example, assume that you specified the trigger source as **External TTL Pos Edge**, set the **Acquisition Duration** field on the **Recording** tab to **5 Seconds**, and clicked the **Record** toolbar button ( Record) or pressed the **F5** key. In this example, the device waits until it detects a rising-edge TTL pulse on external trigger line before acquiring data. When five seconds of data are acquired, acquisition stops.

Refer to the user's manual for your device for information on the supported trigger sources.

Filter Type

If supported by your device, you can configure one of the following filter types:

- **Moving average** – (The default filter setting.) This filter type removes unwanted noise from your measurements and provides a compromise of filter functionality and response time. This filter can be used in any application.

This low-pass filter takes the previous 16 samples, adds them together, and divides by 16.

- **None** – No filter. Provides fast response times, but the data may be difficult to interpret. Use when you want to filter the data yourself.

The data is represented exactly as is when it comes out of the Delta-Sigma A/D converters. Note that Delta-Sigma converters provide substantial digital filtering above the Nyquist frequency.

Generally, the only time it is desirable to use the **None** filter setting is if you are using fast responding thermocouples, sampling them at higher speeds (> 1 Hz), and need as much response speed as possible.

Temperature Units

For thermocouple and RTD measurements, you can select the temperature units (Celsius, Fahrenheit, and Kelvin) into which the voltage data is converted. This setting is applied to all the temperature channels of the device.

You can see which temperature unit will be displayed for each channel in the Configure Devices dialog box, described on [page 60](#).

Single-Ended or Differential Channel Configuration

If your device supports it, you can select the following channel configuration for the A/D subsystem:

- **Single-ended** – Choose this configuration when you want to measure high-level signals, noise is not significant, the source of the input is close to the device, and all the input signals are referred to the same common ground. Refer to the user's manual for your device for wiring information.
- **Differential** – Choose this configuration when you want to measure thermocouple or low-level signals, you are using an A/D converter with high resolution, noise is a significant part of the signal, or common-mode voltage exists. Refer to the user's manual for your device for wiring information.

Input Voltage Range

If your device supports multiple input voltage ranges and/or gains, you can select which effective input range to use for the A/D subsystem. For example, if your device supports an input range of ± 10 V with gains of 1 and 2, two effective input ranges are supported: ± 10 V (± 10 V divided by a gain of 1) and ± 5 V (± 10 V divided by a gain of 2).

Refer to the user's manual for your device for specific information on the input voltage ranges and gains that are supported.



Configuring the Display

Configuring the Appearance of the Channel Display Window	88
Configuring the Appearance of the Channel Plot Window	94
Configuring the Appearance of the Statistics Window	105


Configuring the Appearance of the Channel Display Window

This section describes the how to configure the appearance of the Channel Display window, and includes the following topics:

- Displaying channels in the Channel Display window, described on this page
- Controlling how data is displayed in the Channel Display window, described on [page 90](#)
- Specifying the style of the Channel Display window, described on [page 92](#)

Displaying Channels in the Channel Display Window

You can determine which channels are displayed in the Channel Display window by using the following controls in the Plot and Data Config window:



You can see the names of all enabled channels under the **Channel Name** column in the Plot and Data Config window. Only data from the list of enabled channels is acquired.

Note: If desired, you can change the name of a channel using the **Input Channel Configuration** menu option, described on [page 56](#).

For each enabled channel, you can control which channels are displayed in the Channel Display window using the **Visible Display** checkbox. If a box is checked under the **Visible Display** column, the data for the associated channel is displayed in the Channel Display window. If a box under the **Visible Display** column is unchecked, the data for the associated channel is not displayed in the Channel Display window.

Note: Data for all enabled channels is recorded regardless of whether the channel is visible.

Making All Selected Channels Visible or Hidden in the Channel Display Window at Once

If you want to make all selected channels visible in the Channel Display window at once, select the **Multi-channel Actions** button ( **Actions** ▾), and choose **Selected channels visible in Channel Display**.

If you want to hide all selected channels in the Channel Display window at once, select the **Multi-channel Actions** button ( **Actions** ▾), and choose **Selected channels hidden in Channel Display**.

Showing or Hiding the Visible Display Column


If you wish, you can change whether the **Visible Display** column is shown or hidden by selecting the **Hide/show columns** () button, and selecting **Visible Display**. A checkmark means the column is shown; no checkmark means the column is hidden.

Moving the Visible Display Column

If you wish, you can move the position of the **Visible Display** column by clicking the left-mouse button to select it, dragging it to the right or left, and letting go of the left-mouse button.


Controlling How Data is Displayed in the Channel Display Window

Using the **Channel Display - Control** tab in the Plot and Data Config window, you can control how data is displayed in the Channel Display window.



You can configure the following settings:

- **Hide Unused Channels** – By default, the Channel Display window resembles the front panel of the device and shows up to 48 channels. However, if you want your display to show only the enabled channels rather than all the channels, check the **Hide Unused Channels** box. The following example illustrates how the display looks when three channels are enabled and the **Hide Unused Channels** box is checked.



- **Precision** – You can select the number of significant digits after the decimal point to display; values range from 1 to 8 (2 is the default).


- **Columns** – You can specify how many columns to use when displaying the channels; values range from 1 to 16 (8 is the default). For example, by choosing 1, shown below, you can display each channel, one on top of the other (note that the lowest numbered channel is always at the bottom of the display and the highest numbered channel is at the top of the display):



- **Display Update Rate** – You can choose how fast you want the display of the Channel Display window to be updated. Slide the bar to the left for faster update rates, or slide the bar to the right for slower update rates.
- **Data Reduction Method** – You can choose which value to display in the Channel Display window:
 - **First Value** – The first value in the most recent buffer is displayed for each channel.
 - **Average** – The average value in the most recent buffer is displayed for each channel.
 - **Min** – The minimum value in the most recent buffer is displayed for each channel.
 - **Max** – The maximum value in the most recent buffer is displayed for each channel.

Specifying the Style of the Channel Display Window


Using the Channel Display Style tab, you can specify the style of the Channel Display window.




You can configure the following parameters:

- **Background color** – Allows you to choose a specific color for the background of the Channel Display window. You can select from a number of predefined colors or you can define your own color for the background.
- **Foreground color** – Allows you to choose a specific color for the foreground of the Channel Display window. You can select from a number of predefined colors or you can define your own color for the foreground.
- **Label color** – Allows you to choose a specific color for the label used on the Channel Display window. You can select from a number of predefined colors or you can define your own color for the label.


- **Indicator style** – Allows you to specify how the numbers and letters that represent the data appear. The following choices are available:
 - **7 Segment** – The numbers and letters that represent the data are composed of 7-segment lines.



- **16 Segment** – The numbers and letters that represent the data are composed of 16-segment lines.



- **Mechanical** – The numbers and letters that represent the data appear to be formed by a contiguous line.




Configuring the Appearance of the Channel Plot Window

This section describes the following aspects related to the appearance of the Channel Plot window:

- Displaying channels in the Channel Plot window, described on this page
- Displaying data cursors in the Channel Plot window, described on [page 96](#)
- Specifying the columns of the Channel Plot window, described on [page 97](#)
- Grouping signals in bands on the Channel Plot window, described on [page 99](#)
- Specifying the trace color on the Channel Plot window, described on [page 101](#)
- Controlling how data is plotted the Channel Plot window, described on [page 102](#)
- Specifying the style of the plots in the Channel Plot window, described on [page 104](#)

Displaying Channels in the Channel Plot Window

You can determine which channels are displayed in the Channel Plot window by using the following controls in the Plot and Data Config window:



You can see the names of all enabled channels under the **Channel Name** column in the Plot and Data Config window. Only data from the list of enabled channels is acquired.

Note: If desired, you can change the name of a channel using the **Input Channel Configuration** menu option, described on [page 56](#).

For each enabled channel listed under the **Channel Name** column, you can control which channels are displayed in the Channel Plot window using the **Visible Plot** checkbox. If a box is checked under the **Visible Plot** column, a plot for the associated channel is displayed in the Channel Plot window. If a box under the **Visible Plot** column is unchecked, the plot for the associated channel is not displayed in the Channel Plot window.

Note: Data for all enabled channels is recorded regardless of whether the channel is visible.

Making All Selected Channels Visible or Hidden in the Channel Plot Window at Once

If you want to make all selected channels visible in the Channel Plot window at once, select the **Multi-channel Actions** button ( **Actions** ▾), and choose **Selected channels visible in Channel Plot**.

If you want to hide all selected channels in the Channel Plot window at once, select the **Multi-channel Actions** button ( **Actions** ▾), and choose **Selected channels hidden in Channel Plot**.

Showing or Hiding the Visible Plot Column


If you wish, you can change whether the **Visible Plot** column is shown or hidden by selecting the **Hide/show columns** () button, and selecting **Visible Plot**. A checkmark means the column is shown; no checkmark means the column is hidden.

Moving the Visible Plot Column

If you wish, you can move the position of the **Visible Plot** column by clicking the left-mouse button to select it, dragging it to the right or left, and letting go of the left-mouse button.

Displaying Data Cursors in the Channel Plot Window

You can determine whether data cursors are displayed in the Channel Plot window by using the following controls in the Plot and Data Config window:



For each of the enabled channels, you can choose to display a data cursor in the Channel Plot window using the **Show Cursor** column in the Plot and Data Config window.

If a box is checked under the **Show Cursor** column, a data cursor for the associated channel is displayed in the Channel Plot window. If a box under the **Show Cursor** column is unchecked, a data cursor for the associated channel is not displayed in the Channel Plot window.

You can enable the capability of moving the data cursor using the data-cursor control (), described on [page 48](#). Various options are available for changing the cursor style, line style, and cursor color.

Making All Selected Data Cursors Visible or Hidden at Once

If you want to make all selected data cursors visible in the Channel Plot window at once, select the **Multi-channel Actions** button ( Actions ▾), and choose **Selected data cursors visible**.

If you want to hide all selected data cursors in the Channel Plot window at once, select the **Multi-channel Actions** button ( Actions ▾), and choose **Selected data cursors hidden**.

Showing or Hiding the Show Cursor Column


If you wish, you can change whether the **Show Cursor** column is shown or hidden by selecting the **Hide/show columns** () button, and selecting **Show Cursor**. A checkmark means the column is shown; no checkmark means the column is hidden.

Moving the Show Cursor Column

If you wish, you can move the position of the **Show Cursor** column by clicking the left-mouse button to select it, dragging it to the right or left, and letting go of the left-mouse button.


Specifying the Columns of the Channel Plot Window

You can determine how many columns are displayed in the Channel Plot window by using the following controls in the Plot and Data Config window:



You can specify up to six columns to view in the Channel Plot window.

Under **Plot Column**, select the column (1 to 6) in which to display the selected channel. The following example shows a display of two plot columns, where the thermocouple channels are displayed in column 1 and voltage channels are displayed in column 2:



Changing the Plot Column for All Selected Channels at Once

If you want to change the plot column for all selected channels at once, do the following:

1. Highlight the channels in the Plot and Data Config window that you want to change.
2. Select the **Multi-channel Actions** button ( **Actions** ▾).
3. Choose **Selected channels Plot Column**.
4. Enter the number of plot columns to use.

Showing or Hiding the Plot Column


If you wish, you can change whether the **Plot Column** is shown or hidden by selecting the **Hide/show columns** () button, and selecting **Plot Column**. A checkmark means the column is shown; no checkmark means the column is hidden.

Moving the Plot Column

If you wish, you can move the position of the **Plot Column** by clicking the left-mouse button to select it, dragging it to the right or left, and letting go of the left-mouse button.

Grouping Signals in Bands on the Channel Plot Window


You can group signals in bands in the Channel Plot window by using the following controls in the Plot and Data Config window:



You can choose to display multiple signals in the same band by assigning the same **Signal Group** letter to them. You can specify a value of **A** through **T** for the Signal Group.

For example, to see the data from analog input signals 1 and 2 in the same band, you could set the **Signal Group** for both channels to **A**.

If two analog input channels have a different plot data type (for example, one is temperature and the other is voltage), two Y-axes are displayed for the band, as shown in the following example:



Changing the Signal Group for All Selected Channels at Once

If you want to change the value of the signal group for all selected channels at once, do the following:

1. Highlight the channels in the Plot and Data Config window that you want to change.
2. Select the **Multi-channel Actions** button ( **Actions** ▾).
3. Choose **Selected channels Signal Group**.
4. Enter the value of the signal band to use.

Showing or Hiding the Signal Group Column


If you wish, you can change whether the **Signal Group** column is shown or hidden by selecting the **Hide/show columns** () button, and selecting **Signal Group**. A checkmark means the column is shown; no checkmark means the column is hidden.

Moving the Signal Group Column

If you wish, you can move the position of the **Signal Group** column by clicking the left-mouse button to select it, dragging it to the right or left, and letting go of the left-mouse button.

Specifying the Trace Color on the Channel Plot Window

You can specify the color of the trace on the Channel Plot window by using the following controls in the Plot and Data Config window:



For each channel, select the **Color** column, and then select the color that you want to display for the trace in the Channel Plot window.

Showing or Hiding the Color Column


If you wish, you can change whether the **Color** column is shown or hidden by selecting the **Hide/show columns** () button, and selecting **Color**. A checkmark means the column is shown; no checkmark means the column is hidden.

Moving the Color Column

If you wish, you can move the position of the **Color** column by clicking the left-mouse button to select it, dragging it to the right or left, and letting go of the left-mouse button.

Controlling How Data is Plotted in the Channel Plot Window

Using the Channel Plot Control tab in the Plot and Data Config window, you can control how data is plotted in the Channel Plot window.



You can configure the following settings:

- **Plot update rate**, – Enter a value between 1 and 50 to indicate how often you want the display to be refreshed per second.
- **Smooth scrolling** – You can adjust how the plot scrolls to the left using the **Smooth scrolling** checkbox. If **Smooth scrolling** is checked, the plot attempts to scroll after each data point is added. However, scrolling is limited by the actual update rate. For example, if the **Plot update rate** is set to 50, and 100 points are added per second (determined by the **Recording** settings), the plot scrolls to the left by 2 samples, 50 times per second.

If the **Smooth scrolling** checkbox is unchecked, the plot does not attempt to scroll after every point is added; instead, it scrolls after each buffer is plotted. The buffer size is set to the FFT size.

- **Disable during acquisition** – This checkbox is provided for fast data acquisition boards, such as the DT9832, which acquire data faster than the application can display it.


If the **Disable during acquisition** checkbox is checked, no data is displayed in the Channel Plot window during acquisition. When acquisition is finished, the data is displayed in the Channel Plot window.

If the **Disable during acquisition** checkbox is unchecked, the data is displayed in the Channel Plot window as the data is acquired.

- Under **Time domain X axis units**, select the units for the x-axis as one of the following:
 - **Sample number** – The units for the x-axis are represented as the number of samples (0 to the maximum number of samples acquired).
 - **Relative time** – The units for the x-axis are represented as the recording time from 0 to the total recording time.
 - **Absolute time** – The units for the x-axis are represented as the actual time of acquisition based on the system clock. If you select absolute time, you can select whether to represent the time in 24-hour (military) format or 12-hour format.
- **Display Milliseconds** – Check this checkbox if you want to see the data on the x-axis displayed in milliseconds; this setting is useful when you zoom into the data with the data cursors shown. If this checkbox is unchecked, the data on the x-axis is displayed in seconds.
- **Display Day** – If **Absolute Time** is selected and you check the **Display Day** checkbox, the x-axis shows dd:hh:mm:ss, where *dd* is the day of the month, *hh* is hours, *mm* is minutes, and *ss* is seconds. If **Relative Time** is selected, the value for day starts at 0 and increments by one for each subsequent day. You can also set the value for day in the x-axis options if the **Display Day** checkbox is selected.
- Use the **Plot height** slider bar, to determine the relative height of each plot in the Channel Plot window. Slide the control to the right to increase the height; slide the control to the left to decrease the height. Note that the entire screen is always filled, so, typically, this setting is useful when you want to view many plots at once.

Specifying the Style of the Plots in the Channel Plot Window

The Channel Plot Style tab allows you to specify the style of the plots that are displayed in the Channel Plot window.




You can configure the following settings:

- Use the **Background Color** box to choose a different color for the background of the Channel Plot window.
- Use the **Axis color** box to choose a different color for the axes of the Channel Plot window.
- Use the **Grid line color** box to choose a different color for the grid lines of the Channel Plot window.
- In the **Trace thickness** box, enter the value between 1 and 5 to set the thickness of the line used by the trace on the Channel Plot window, where 1 is the thinnest line and 5 is the thickest line.
- Under **Plot Header**, click the **Visible** checkbox if you want a header displayed for the data on the plot, and then enter the text for the header. By default, the header is called *Test Data*. You can also select the color for the header and the font in which to display the header.
- Under **X-Axis Label**, you can select the color for the label of the x-axis and the font in which to display the x-axis label.
- Under **Y-Axis Label**, you can select the color for the label of the y-axis and the font in which to display the y-axis label.

Configuring the Appearance of the Statistics Window

You can determine whether statistics are displayed in the Statistics window by using the following controls in the Plot and Data Config window:



For each enabled channel listed under the **Channel Name** column, you can control whether statistics are displayed in the Statistics window using the **Visible Statistics** checkbox. If a box is checked under the **Visible Statistics** column, the statistics for the associated channel are listed in the Statistics window. If a box under the **Visible Statistics** column is unchecked, the statistics for the associated channel are not displayed in the Statistics window.

Making Statistics for All Selected Channels Visible or Hidden in the Statistics Window at Once

If you want to make statistics for all selected channels visible in the Statistics window at once, select the **Multi-channel Actions** button ( **Actions** ▾), and choose **Selected channels visible in Statistics Display**.

If you want to hide statistics for all selected channels in the Statistics window at once, select the **Multi-channel Actions** button ( **Actions** ▾), and choose **Selected channels hidden in Statistics Display**.

Showing or Hiding the Visible Statistics Column

If you wish, you can change whether the **Visible Statistics** column is shown or hidden by selecting the **Hide/show columns** () button, and selecting **Visible Statistics**. A checkmark means the column is shown; no checkmark means the column is hidden.

Moving the Visible Statistics Column

If you wish, you can move the position of the **Visible Statistics** column by clicking the left-mouse button to select it, dragging it to the right or left, and letting go of the left-mouse button.



Example Using QuickDAQ

Overview	108
Configure the Channels	109
Configure the Parameters of the Acquisition Config Window	111
Configure the Appearance of the Channel Display Window	113
Configure the Appearance of the Channel Plot Window	114
Configure the Appearance of the Statistics Window	117
Position the Windows	118
Start the Measurement	120

Overview

This chapter describe how to use QuickDAQ to configure and run a measurement application.


For this example, the following sensors are connected to a MEASURpoint instrument:

- T thermocouple is connected to analog input channel 0
- 4-wire, Euro PT1000 RTD is connected to analog input channel 8
- ± 10 V input signal is connected to analog input channel 16

Configure the Channels

Configure the channels as follows:

1. Configure each analog input channel by clicking the **Configuration** menu, and clicking **Input Channel Configuration**, or by clicking the **Input Channel Configuration** toolbar button ().
2. Enable analog input channels 0, 8, and 16 by clicking the checkbox under the **Enable** column.



Channel	Enable	Channel Name	Sensor Type	Engineering Unit (EU)	mV/EU	EU Offset	Point #
Deskunit-0	<input checked="" type="checkbox"/>	T Therm	Type T	Deg C		0	1
Deskunit-1	<input type="checkbox"/>	TC.1	Type J	Deg C		0	2
Deskunit-2	<input type="checkbox"/>	TC.2	Type J	Deg C		0	3
Deskunit-3	<input type="checkbox"/>	TC.3	Type J	Deg C		0	4
Deskunit-4	<input type="checkbox"/>	TC.4	Type J	Deg C		0	5
Deskunit-5	<input type="checkbox"/>	TC.5	Type J	Deg C		0	6
Deskunit-6	<input type="checkbox"/>	TC.6	Type J	Deg C		0	7
Deskunit-7	<input type="checkbox"/>	TC.7	Type J	Deg C		0	8
Deskunit-8	<input checked="" type="checkbox"/>	PT1000 RTD	Euro PT1000	Deg C		0	9
Deskunit-9	<input type="checkbox"/>	RTD.9	Euro PT1000	Deg C		0	10
Deskunit-10	<input type="checkbox"/>	RTD.10	Euro PT1000	Deg C		0	11
Deskunit-11	<input type="checkbox"/>	RTD.11	Euro PT1000	Deg C		0	12
Deskunit-12	<input type="checkbox"/>	RTD.12	Euro PT1000	Deg C		0	13
Deskunit-13	<input type="checkbox"/>	RTD.13	Euro PT1000	Deg C		0	14
Deskunit-14	<input type="checkbox"/>	RTD.14	Euro PT1000	Deg C		0	15
Deskunit-15	<input type="checkbox"/>	RTD.15	Euro PT1000	Deg C		0	16
Deskunit-16	<input checked="" type="checkbox"/>	Voltage In	+/- 10V	V	1000	0	17
Deskunit-17	<input type="checkbox"/>	MB.17	+/- 10V	V	1000	0	18

3. Under the **Channel Name** column, enter a meaningful name for each channel. For this example, enter the following names:
 - For analog input channel 0, enter **T Therm** as the channel name.
 - For analog input channel 8, enter **PT1000 RTD** as the channel name.
 - For analog input channel 16, enter **Voltage In** as the channel name.
4. Under the **Sensor** column, select the following sensor types for the analog input channels:
 - For analog input channel 0, select **Type T** as the thermocouple type.
 - For analog input channel 8, select **Euro PT1000** as the RTD type.
 - For analog input channel 16, select **+/-10V** as the input voltage range.

5. Under the **Engineering Units** column, **Deg C** is selected by default. If you want to change this setting, change the temperature units under the **Acquisition Config - Acquisition** tab.


In this example, Deg C is used.

6. If you know the offset for your calibrated thermocouple and RTD, enter it under the **EU Offset** column. For this example, leave **0** as the EU offset for the thermocouple and RTD channels and **1000** as the EU offset for the voltage input channel.
7. Leave the test point values for each channel unchanged.
8. Click **Close** to close the Channel Configuration dialog box.


Configure the Parameters of the Acquisition Config Window

For this example, set the Acquisition Config parameters as follows:

1. Click the **Recording** tab.



2. For **Filename generation**, select **Filename**.
3. Enter a meaningful name for the data file.
In this example, QuickDAQ Data.hpf is used.
4. Leave the **Enable Continuous Acquisition** checkbox unchecked.
5. For **Acquisition Duration**, select **1 minute** as the time to acquire the measurement data.
The amount of available disk space is shown; in addition, the number of scans in the Acquisition Info area is updated based on the acquisition duration that is selected.
6. For **X Axis Span**, enter **5 seconds** as the span for the x-axis.
7. Click the **Acquisition** tab.



8. For this example, ensure that the following default settings are used:
 - **Sampling Frequency:** 10 Hz
 - **Trigger Source:** Software
 - **Temperature Unit:** Celsius
 - **Filter Type:** Moving Average
9. If desired, hide the **Acquisition Config** window by clicking the **Auto-Hide** pin () in the top, right corner of the window.

Configure the Appearance of the Channel Display Window


Configure the appearance of the Channel Display window as follows:

1. Ensure that the **Visible Display** column in the **Plot and Data Config** window is checked for all three enabled channels.

Channel Name	Visible Plot	Visible Display	Visible Statistics	Show Cursor	Plot Column	Signal Group	Color
Deskunit.T Therm	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1	A	Red
Deskunit.PT1000 RTD	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1	A	Blue
Deskunit.Voltage In	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1	B	Brown

2. Click the **Channel Display - Style** tab, and select the color scheme that you want for the Channel Display window.

In this example, black is used for the background color, green is used for the foreground color, and white is used for the label color.




3. Leave the indicator style as **7 segment**.

Configure the Appearance of the Channel Plot Window


Configure the appearance of the Channel Plot window as follows:

1. In the **Plot and Data Config** window, set up the following parameters:
 - a. Ensure that the **Visible Plot** column is checked for all three enabled channels.
 - b. Leave the **Show Cursor** column unchecked for all three enabled channels.
 - c. Under **Plot Column**, use the default plot column setting of 1 for all three enabled channels.
 - d. Under the **Signal Group** column, select **A** for the thermocouple and RTD channels, and select **B** for the voltage input channel.
 - e. Under the **Color** column, assign a unique color to each trace.




Channel Name	Visible Plot	Visible Display	Visible Statistics	Show Cursor	Plot Column	Signal Group	Color
Deskunit.T Therm	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1	A	Red
Deskunit.PT1000 RTD	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1	A	Blue
Deskunit.Voltage In	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1	B	Brown

2. Click the **Channel Plot - Control** tab, and slide the **Plot height** bar to the left until you can see both plots on the screen at once.



3. Leave the following settings unchanged:
 - **Plot update rate:** 1
 - **Smooth scrolling:** unchecked
 - **Disable during acquisition:** unchecked
 - **Time domain X axis units:** Relative time
 - **Display Milliseconds:** unchecked
 - **Display Days:** unchecked
4. In the display area, click the tab for the **Channel Plot** window.
5. Click the **Show Legend** control () on the toolbar.
6. For the top plot in this window, change the text for the label on the x-axis, by doing the following:
 - a. Right-click on the label.
 - b. Select **Edit Label**.
 - c. Enter the following text: **Thermocouple and RTD Channels**
7. For the bottom plot in this window, change the text for the label on the x-axis, by doing the following:
 - a. Right-click on the label.
 - b. Select **Edit Label**.


- c. Enter the following text: **Voltage Channels**
The Channel Plot window should appear as follows:



Configure the Appearance of the Statistics Window

Configure the appearance of the Statistics window as follows:

1. Ensure that the **Visible Statistics** column in the **Plot and Data Config** window is checked for all three enabled channels:



The screenshot shows the 'Plot and Data Config' window with a table of channel settings. The table has columns for Channel Name, Visible Plot, Visible Display, Visible Statistics, Show Cursor, Plot Column, Signal Group, and Color. Three channels are listed: Deskunit.T Therm (red), Deskunit.PT1000 RTD (blue), and Deskunit.Voltage In (brown). All 'Visible Statistics' checkboxes are checked.


Channel Name	Visible Plot	Visible Display	Visible Statistics	Show Cursor	Plot Column	Signal Group	Color
Deskunit.T Therm	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1	A	Red
Deskunit.PT1000 RTD	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1	A	Blue
Deskunit.Voltage In	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1	B	Brown

2. If desired, hide the **Plot and Data Config** window by clicking the **Auto-Hide** pin () in the top, right corner of the window.

Position the Windows

If you want to see the data that is displayed in the Channel Display, Channel Plot, and Statistics windows at once, you need to move the windows to different locations in the display area.

In the following example, the Channel Display window is located at the top of the display area, the Channel Plot window is located in the middle of the display area, and the Statistics window is located at the bottom of the display area:



Perform the following steps to position the Channel Display window at the top of the display area, the Channel Plot window in the middle of the display area, and the Statistics window at the bottom of the display area:

1. Click the tab for the **Statistics** window, drag the window toward the middle of the display area, move the mouse over the guide on the bottom of the guide diamond, and then release the mouse button.

The Statistics window is now placed at the bottom of the display area.

2. Click the tab for the **Channel Plot** window, drag the window toward the middle of the display area, move the mouse over the guide on the bottom of the guide diamond, and then release the mouse button.


The Channel Plot window is now placed in the middle of the display area, revealing the Channel Display window at the top of the display area.

3. Resize each window, as desired.

Start the Measurement

Once you have configured the channels and the display area, start acquisition and log data to disk by clicking the **Record** toolbar button ().

Results similar to the following are displayed in the display area.



If desired, you can view the data in Excel by clicking the **Open Current Data in Excel** toolbar button ().



Support

Troubleshooting	122
Technical Support.....	123

Troubleshooting

If you are performing an acquisition for a long duration, you may see that acquisition stops if your computer's power options are not set correctly. If this problem occurs, do the following to change the power options of your computer:

1. Go to the Control Panel application for your computer.
2. Select **Power Options**.
3. For the **Put the Computer to Sleep** option, select **Never**.

Should you experience other problems using QuickDAQ, do the following:

1. Read all the appropriate sections of this manual. Make sure that you have added any "Read This First" information to your manual and that you have used this information.
2. Check for a README file on the CD. If present, read this file for the latest installation and usage information.
3. Check that you have installed your data acquisition devices properly. For information, refer to the documentation supplied with your devices.
4. Check that you have installed the latest device drivers for your data acquisition devices. For information, refer to the documentation supplied with your devices.
5. Check that you have installed your software properly. For information, refer to [page 16](#)
6. Search the Data Translation web site (www.datatranslation.com) for information about QuickDAQ.
7. Search the Knowledgebase in the Support section of the Data Translation web site (at www.datatranslation.com) for an answer to your problem.

If you are still having problems, Data Translation's Technical Support Department is available to provide technical assistance to licensed users.

Technical Support

If you have any difficulty using QuickDAQ, Data Translation's Technical Support Department is available to provide technical assistance.

To request technical support, go to our web site at <http://www.datatranslation.com> and click on the **Support** link.

Note: Any unhandled exceptions that occur when running QuickDAQ are captured and displayed in a dialog box; these exceptions are also appended to a file called QuickDAQErrLog.log off the root directory (C:\QuickDAQErrLog.log). If you receive an unhandled exception, please email the QuickDAQErrLog.log file to the Data Translation Technical Support Department at support@datx.com.

When requesting technical support, be prepared to provide the following information:

- The version of QuickDAQ that you are using
- The serial number of your data acquisition device

A

- AC coupling 61
- Acquisition Config window 38
 - Acquisition tab 84
 - Recording tab 81
- acquisition duration 82
- acquisition mode 13
- Acquisition Status window 54
- Acquisition tab 39, 84
- analog input channel settings
 - bridge type 70
 - calibrate 66, 71
 - channel name 58
 - Configuration and Calibration wizard 64
 - coupling type 61
 - current source 61
 - direction 62
 - enabling channels 58
 - engineering units 60, 61, 63, 66, 70, 75
 - excitation voltage 66, 70
 - gage factor 70
 - IEPE 61
 - lead wire resistance 66, 70
 - maximum range 70
 - minimum range 70
 - multi-range voltage inputs 58
 - nominal gage 66, 70
 - point # 61, 62, 63, 76
 - Poisson ratio 71
 - range 60, 61
 - remote sense lines 66, 70
 - sensor offset value 60, 62, 63, 76
 - sensor scaling factor 60, 62, 63
 - sensor scaling value 76
 - sensor type 58
 - shunt resistor 64
 - strain 63
 - temperature 58
 - transducer capacity 66
 - transducer rated output 66
 - voltage 62
- analog threshold negative edge trigger 85
- analog threshold positive edge trigger 85
- AppData folder 25
- Auto-Hide pin 36
- Axes Scroll control 46

- Axes Zoom control 46
- axis color 104
- Axis Mouse Mode 30
 - Scroll 30
 - Zoom 30

B

- background color
 - Channel Display window 92
 - Channel Plot window 104
- backup configuration file 29
- bands, signals 99
- bridge configuration
 - Full Bridge Axial Poisson 70
 - Full Bridge Bending 70
 - Full Bridge Bending Poisson 70
 - Half Bridge Bending 70
 - Half Bridge Poisson 70
 - Quarter Bridge 70
 - Quarter Bridge Temp Comp 70
- bridge type 70
- buttons 33

C

- calibrate 66, 71
- channel configuration 86
- Channel Display - Control tab 90
- Channel Display - Style tab 92
- Channel Display window 52
 - background color 92
 - columns 91
 - configuring the appearance 88
 - data reduction method 91
 - display update rate 91
 - displaying channels 88
 - foreground color 92
 - indicator style 93
 - label color 92
 - precision 90
- channel name 58
 - Configure Devices dialog 58
 - Plot and Data Config window 88, 94
- Channel Plot - Control tab 102
- Channel Plot - Style tab 104

- Channel Plot window 41
 - configuring the appearance 94
 - controls 46, 47, 48, 49, 50
 - displaying channels 94
 - displaying data cursors 96
 - grouping signal bands 99
 - specifying plot columns 97
 - specifying the trace color 101
 - channel visibility 89, 95
 - Channel Display window 89
 - Channel Plot window 95
 - Statistics window 105
 - channels, enabling 58
 - clock prescale 79
 - Close Hpf Data menu option 26
 - color
 - axis 104
 - background of Channel Display window 92
 - background of the Channel Plot window 104
 - foreground of Channel Display window 92
 - grid line 104
 - label for the Channel Display window 92
 - trace 101
 - Color column 101
 - Comma Delimited Text file format 27
 - Config folder 28
 - Configuration and Calibration wizard 64
 - configuration file 28
 - saving and loading 80
 - Configuration menu 31
 - configuring input channels 56
 - analog input channels (IEPE) 61
 - analog input channels (multi-range voltage) 58
 - analog input channels (strain) 63
 - analog input channels (temperature) 58
 - analog input channels (voltage) 62
 - changing the channel name 58
 - counter channels 77
 - enabling channels 58
 - engineering units 60, 63
 - quadrature decoder channels 79
 - sensor offset value 60, 63
 - sensor scaling factor 60, 63
 - sensor type 58
 - tachometer channels 76
 - test point number 61, 63
 - configuring statistics 105
 - configuring the plot style 104
 - continuous acquisition 82
 - Control tab
 - Channel Display 90
 - Channel Plot 102
 - controls of the Channel Plot window 46
 - Axes Scroll 46
 - Axes Zoom 46
 - Copy to Clipboard 49
 - Data Cursor 48
 - Link Cursors to Selected 47
 - Link X Axes to Selected 47
 - Link Y Axes to Selected 47
 - Page Setup 49
 - Preview 49
 - Print 49
 - Save Plot Image 49
 - Select 47
 - Show Data Point Markers 50
 - Show Legend 50
 - Tracking Pause 46
 - Tracking Resume 46
 - Zoom All to Fit in View Y 47
 - Zoom Box 47
 - Zoom-In All 47
 - Zoom-Out All 47
 - conventions used 10
 - Copy plot data to clipboard menu option 29
 - Copy plot image to clipboard 29
 - Copy to Clipboard control 49
 - counter settings 77
 - engineering units 78
 - mSec per Hz 78
 - start edge 78
 - stop edge 78
 - coupling type 61
 - CSV file format 27
 - current source 61
 - cursor style
 - frequency 48
 - peak-peak 48
 - period 48
 - value-XY 48
- ## D
- dash line style 49
 - dashdot line style 49
 - Data Cursor control 48
 - data cursors 96
 - data file 25, 33
 - data file name 81, 82
 - Data folder 27, 49
 - data reduction method 91
 - DC coupling 61

Device Selection window 17
 device status 54
 differential channel configuration 86
 digits after decimal point 42
 disable during acquisition 102
 Display Day checkbox 103
 Display Milliseconds checkbox 103
 display update rate 91
 displaying channels
 Channel Display window 88
 Channel Plot window 94
 displaying data cursors 96
 docking windows 35
 dot line style 49

E

edge of tachometer 77
 edge, counters 78
 Edit menu 29
 Copy plot data to clipboard 29
 Copy plot image to clipboard 29
 editing label of x-axis 44
 enabling channel display
 Channel Display window 89
 Channel Plot window 95
 Statistics window 105
 enabling channels 58
 engineering unit offset 60, 62, 63, 76
 engineering unit scaling 76
 engineering units 60, 63
 analog input 61, 66, 70, 75
 counter 78
 quadrature decoder 79
 tachometer 76
 examples 107
 excitation voltage 66, 70
 Exit menu option 29
 Exit without saving current configuration menu
 option 29
 Export Data button 33
 Export Data menu option 26
 external TTL negative-edge trigger 85
 external TTL positive-edge trigger 85

F

features 12
 file formats
 CSV 27
 TXT 27

File menu 25
 Close Hpf Data File menu 26
 Exit 29
 Exit without saving current configuration 29
 Export Data menu 26
 Load Configuration 28
 New Hpf Data File 25
 Open Current Data in Excel 28
 Open Hpf Data File 25
 Page Setup 28
 Print 28
 Print Preview 28
 Save Configuration 28
 Save Current Plot Image 27
 file reader mode 13
 filename base 82
 filename generation 81
 filter type 85
 foreground color, Channel Display window 92
 format of y-axis 43
 frequency cursor style 48
 frequency of acquisition 84
 Full Bridge Axial Poisson configuration 70
 Full Bridge Bending configuration 70
 Full Bridge Bending Poisson configuration 70
 full-bridge-based sensor parameters 65

G

gage factor 70
 getting started 17
 grid line color 104
 gridlines
 x-axis 44
 y-axis 42
 grouping signal bands 99

H

Half Bridge Bending configuration 70
 Half Bridge Poisson configuration 70
 hardware TEDS 65
 header 104
 height of the plot 103
 Help button 34
 Help menu 32
 Hide Unused Channels checkbox 90
 Hide/show columns button
 Color 101
 Plot Column 99
 Show Cursor 97

- Signal Group 100
- Visible Display 89
- Visible Plot 95
- Visible Statistics 106

hiding columns

- Color column 101
- Plot column 99
- Show Cursor column 97
- Signal Group column 100
- Visible Display column 89
- Visible Plot column 95
- Visible Statistics column 106

hiding windows 36

I

- index mode 79
- indicator style, Channel Display window 93
- Input Channel Configuration button 34
- Input Channel Configuration menu option 56
- Input Channel Configuration toolbar button 56
- input range 60, 61
- input voltage range 86
- installing the software 16
- interface 24
- interval 83
- IP address 18

L

label

- X-axis 104
- Y-axis 104

label color, Channel Display window 92

label for x-axis, editing 44

lead wire resistance 66, 70

left edge 45

lin/log scaling, y-axis 43

line style

- dash 49
- dashdot 49
- dot 49
- solid 49

Link Cursors to Selected control 47

Link X Axes to Selected control 47

Link Y Axes to Selected control 47

Load Configuration menu option 28

M

- maximum range 70

- maximum RPM value 76

menus 25

- Configuration 31
- Edit 29
- File 25
- Help 32
- Plot 30
- Record 29
- Windows 31

minimum range 70

modes of operation 13

- acquisition 13
- file reader 13

moving columns

- Color column 101
- Plot column 99
- Show Cursor column 97
- Signal Group column 100
- Visible Display column 89
- Visible Plot column 95
- Visible Statistics column 106

moving windows 35

Multi-channel Actions button

- Disable all Channels 58
- Disable all Selected Channels 58
- Enable all Channels 58
- Enable all Selected Channels 58
- Selected channels hidden in Channel Display 89
- Selected channels hidden in Channel Plot 95
- Selected channels hidden in Statistics Display 105
- Selected channels Plot Column 98
- Selected channels Signal Group 100
- Selected channels visible in Channel Display 89
- Selected channels visible in Channel Plot 95
- Selected channels visible in Statistics Display 105
- Selected data cursors hidden 96
- Selected data cursors visible 96
- Set all Channel Coupling 61
- Set all Channel Current Source 61
- Set all Channel Units 62
- Set all Multi-Range Channels 59
- Set all RTD Channels 59
- Set all Selected Channel Units 60, 62, 63
- Set all Thermocouple Channels 59
- Set all Voltage Channel Units 60, 63

mV per engineering unit 60, 62, 63

N

- naming channels 58, 88, 94
- New HPF Data File button 33

New Hpf Data menu option 25
 nominal gage 66, 70
 number of scans 83

O

offset 60, 62, 63, 76
 offset nulling 66, 71
 Open Current Data in Excel button 33
 Open Current Data in Excel menu option 28
 Open HPF Data File button 33
 Open Hpf Data menu option 25

P

page left 45
 page right 45
 Page Setup control 49
 Page Setup menu option 28
 Pause menu option 30
 pause tracking 44
 peak-peak cursor style 48
 period cursor style 48
 Plot and Data Config window 40
 Plot Area Mouse Mode 30

- Cursor 30
- Select 30
- Zoom 30

 plot columns 97

- changing the value for all channels at once 98
- moving 99
- showing or hiding 99

 Plot Header 104
 plot height 103
 Plot menu 30

- Cursor (Plot Area Mouse Mode) 30
- Scroll (Axis Mouse Mode) 30
- Select (Plot Area Mouse Mode) 30
- Zoom (Axis Mouse Mode) 30
- Zoom (Plot Area Mouse Mode) 30

 plot style 104
 plot update rate 102
 point # 61, 62, 63, 76
 Poisson ratio 71
 power options 122
 precision

- Channel Display window 90
- y-axis 42

 Preview control 49
 Print control 49
 Print menu option 28

Print Preview menu option 28

Q

quadrature decoder channel settings 79
 quadrature decoder settings 79

- clock prescale 79
- engineering units 79
- index mode 79
- pulses/rev 79
- X4 scaling 79

 Quarter Bridge configuration 70
 Quarter Bridge Temp Comp configuration 70

R

range 60, 61
 Record button 34
 Record menu 29

- Pause 30
- Start 29
- Stop 30

 Recording tab 38, 81
 related documents 10
 remote sense lines 66, 70
 Reset Windows Layout to Default Layout menu

- option 24, 31

 Reset Windows Layout to Last Saved menu option 31
 resetting the window layout 37
 resizing windows 35
 resolution 14
 resume tracking 45
 right edge 45
 RPM multiplier 76
 RPM value 76

S

sample hpf file 25, 33
 sample interval 83
 sample rate 83
 sampling frequency 84
 Save Configuration menu option 28
 Save Current Plot Image menu option 27
 Save Plot Image control 49
 scaling 76

- x-axis 44
- y-axis 42

 scans 83
 scroll here 45

- scroll left 45
- scroll right 45
- scrollbar, x-axis 29, 34, 45, 46
- scrolling options 45
 - left edge 45
 - page left 45
 - page right 45
 - right edge 45
 - scroll here 45
 - scroll left 45
 - scroll right 45
- seeing hidden files 25
- Select control 47
- sensor direction 62
- sensor offset value 60, 62, 63, 76
- sensor scaling factor 60, 62, 63
- sensor scaling value 76
- sensor type 58
- setting up the x-axis 43
- setting up the y-axis 42
- Show Cursor column 96
- show data cursors 96
- Show Data Point Markers control 50
- Show Legend control 50
- showing columns
 - Color column 101
 - Plot column 99
 - Show Cursor column 97
 - Signal Group 100
 - Visible Display column 89
 - Visible Plot column 95
 - Visible Statistics column 106
- shunt calibration 66, 71
- shunt resistor 64
- signal bands 99
- Signal Group 99
- Signal Group column 99
 - changing the value for all selected channels at once 100
 - moving 100
 - showing or hiding column 100
- single-ended channel configuration 86
- smooth scrolling 102
- software trigger 85
- solid line style 49
- specifying plot columns of the Channel Plot window 97
- specifying the trace color 101
- start edge, counters 78
- Start menu option 29
- statistics visibility 105

- Statistics window 53
- statistics, configuring 105
- Stats tab 105
- status 54
- Stop button 34
- stop edge, counters 78
- Stop menu option 30
- strain
 - maximum 70
 - minimum 70
- strain gage parameters 69
- Style button 34
- Style tab
 - Channel Display 92
 - Channel Plot 104
- support 123
- supported devices 12
- supported functions 12

T

- Tab Delimited Text file format 27
- tabs
 - Acquisition 39
 - Recording 38
- tachometer settings 76
 - edge 77
 - engineering units 76
 - mSec per Hz 77
 - RPM multiplier 76
 - RPM value 76
 - ticks per revolution 76
- technical support 123
- TEDS 65
- temperature units 86
- test point number 61, 62, 63, 76
- threshold trigger 85
- ticks per revolution 76
- time-domain x-axis units 103
- toolbar buttons 33
 - Export Data 33
 - Help 34
 - Input Channel Configuration 34
 - New HPF Data File 33
 - Open Current Data in Excel 33
 - Open HPF Data File 33
 - Record 34
 - Stop 34
 - Style 34
- trace color 101
- trace thickness 104

tracking
 Pause [44, 46](#)
 Resume [45, 46](#)
 transducer capacity [66](#)
 transducer rated output [66](#)
 trigger sources
 analog threshold negative edge [85](#)
 analog threshold positive edge [85](#)
 external TTL negative-edge [85](#)
 external TTL positive-edge [85](#)
 software [85](#)
 troubleshooting checklist [122](#)
 TXT file format [27](#)

U

units
 engineering [60, 61, 63, 66, 70, 75, 76, 78, 79](#)
 time-domain x-axis [103](#)
 user interface [24](#)

V

value X-Y cursor style [48](#)
 virtual TEDS [65](#)
 visibility
 channels in Channel Display window [89](#)
 channels in Channel Plot window [95](#)
 channels in Statistics window [105](#)
 channels in the Statistics window [105](#)
 data cursors [96](#)
 Visible Display column [89](#)
 Visible Plot column [95](#)
 Visible Statistics column [105, 106](#)
 voltage range [86](#)
 voltage-based sensors parameters [75](#)

W

windows
 Acquisition Config [38](#)
 Acquisition Status [54](#)
 Channel Display [52](#)
 Channel Plot [41](#)
 docking [35](#)
 hiding [36](#)
 moving [35](#)
 Plot and Data Config [40](#)
 resetting [37](#)
 resizing [35](#)
 Statistics [53](#)

Windows menu [31](#)
 Acquisition Config [31](#)
 Channel Display [31](#)
 Channel Plot [31](#)
 Channel Statistics [31](#)
 Plot and Data Config [31](#)
 Reset Windows Layout to Default Layout [24, 31](#)
 Reset Windows Layout to Last Saved [31](#)

X

x axis span [82](#)
 X4 scaling [79](#)
 x-axis
 gridlines [44](#)
 scaling [44](#)
 X-Axis label [104](#)
 x-axis settings [43](#)

Y

y-axis
 format of axis [43](#)
 gridlines [42](#)
 lin/log scaling [43](#)
 precision [42](#)
 scaling [42](#)
 Y-Axis label [104](#)
 y-axis settings [42](#)

Z

Zoom All to Fit in View Y control [47](#)
 Zoom Box control [47](#)
 zoom to fit all
 x-axis [44](#)
 y-axis [43](#)
 zoom to fit in view, y-axis [43](#)
 Zoom-In All control [47](#)
 Zoom-Out All control [47](#)

